

Trainings ▾

General Information

Component	Wrench Size	Torque Value	
		N•m	ft-lb
Oil Pan Drain Plug	1-1/4	88	65
Turbocharger Mounting Nuts	16 mm	68	50
Fan Drive Idler Pulley Shaft Locknut		165 to 190	120 to 140
Injector/Valve Adjusting Screw Locknut	3/4 in.	61	45
Engine Brake Adjusting Screw Locknut		50	40
Fuel Pump Mounting Capscrews	7/16 in	47	35
Fuel Pump Bracket to Cylinder Block		47	35
Fuel Pump Bracket to Fuel Pump Housing	7/16 in	11	95 in-lb
Rocker Lever Cover Capscrews	13 mm	15	130 in-lb
Injector Hold-down Clamps		75	55
Crankcase Breather Cover Bolts	6 mm	.68	6 in-lb
Aftertreatment V-Band Clamps	10 mm	20	180 in-lb
Differential Pressure Sensing Tube Nuts	5/8	55	40
Aftertreatment Mounting Capscrews	10 mm	20	180 in-lb

