

## Trainings ▾

### Remove

Remove the rear gear housing capscrews and housing.

