

Trainings ▾

Install

Install the push rods into the sockets of the valve tappets.

Lubricate the push rods sockets with clean lubricating engine oil.

Note : The push rods and tappets **must** be installed in the same cylinder and intake or exhaust position from which they were removed.

