

Trainings ▾

Remove

Remove the capscrew and belt tensioner from the bracket.

Note : Some belt tensioners are mounted to the water inlet connection.

