

Trainings ▾

Remove

Remove the two capscrews securing the accessory drive to the rear gear housing.

Remove the accessory drive and gasket.

Note : For front gear train engines it may be necessary to remove the external oil supply tube.

