

Trainings ▾

Install

Note : The holes shown in the illustration are drilled through. Apply liquid Teflon™ sealant to the capscrews.

Install the aftercooler housing and a new gasket.

Torque Value: 24 n•m [212 in-lb]

Install the coolant supply tube (1) and coolant return tube (2).

Torque Value: 8 n•m [71 in-lb]

