

Trainings ▾

Remove

Remove the coolant supply tube (1) and the coolant return tube (2).

Remove the aftercooler housing and gasket.

