

Trainings ▾

Install

Install the crossover tube and clamps in the reverse order of removal.

Tighten the clamps.

Torque Value: 8 n•m [71 in-lb]

