

Trainings ▾

Remove

Loosen the hose clamps, and position the hose so the crossover tube can be removed.

