

Trainings ▾

Remove

Remove the capscrews from the turbocharger oil drain tube.

Pull the drain line out of the drain line boss.

