

Trainings ▾

Remove

Remove the oil supply line from the oil filter head.

Remove the oil supply line from the turbocharger bearing housing.

