

Trainings ▾

Select Service Tools

Recommended Cummins® Service Tools

- No recommended Cummins® service tools.

Additional Service Items

- No additional service items required.

General Information

Functionality of the C Command Connect and Connect Premier Marine Panel System **must** be tested before leaving the dock after a service event of the system.

Check the following for proper operation of each engine individually to confirm physical switch operation and display functionality.

- For each engine, turn ON the system enable switch(s). Verify the display(s) power ON by viewing data information on the screen.
- With the system enable switch(s) ON, verify external alarm horn sounds by placing an ED-4 display into DEMO mode. After confirming the external alarm horn sounds, disable the ED-4 display DEMO mode.
- With the system enable switch(s) ON, verify the ED-5/ED-7 display touchscreen is functional by scrolling through data screen, accessing alarm information by alarm soft button on the data screen.
- For application using the Remote Keypad, with the system enabled switch(s) ON, verify the keypad is functional by using the Up, Down, Left, Right keys to scroll through data screen, accessing alarm information, accessing soft buttons to open menu and backlight controls.
- With the system enable switch(s) ON, turn the dimmer (if equipped) to verify the display(s) brightness is adjustable.
- With the system enable switch(s) ON. Press the start switch for each engine to verify the engine starts.
- With the engine in neutral and idling, verify the display(s) function properly for that engine and there are no active faults on the display(s). For example, check the battery voltage, engine oil pressure, and that the engine coolant temperature increases as the engine idles. It is also important to check the vessel sensor information displayed on the ED-4/ED-5/ED-7;

such as transmission gear oil pressure and temperature, rudder angle, and fuel level. If equipped, verify proper generator voltage while running.

- With the engine in neutral and idling, check the operation of all system enable switches, including any E-stop switches, engine stop switches, lanyard switches, engine key switches, and any other devices intended to shut down the engine, if equipped. After testing each engine individually, start all engines and perform a system shutdown using the switches.
- Although **not** part of the C Command Connect and Connect Premier Marine Panel System, with the engine(s) running, verify throttle and correct gear control of engine(s).
- Use the following procedure for additional information. Refer to Procedure 101-013 in Section 1. (</qs3/pubsys2/xml/en/procedures/513/513-101-013.html>)