

OEM Installed Vessel Sensor Information Missing or Intermittent on Display

Symptoms

- Sensor parameters or data does **not** display correctly or is incorrect.

How To Use This Tree

This symptom tree can be used to troubleshoot display data issues. Start by performing Step 1 troubleshooting. Step 2 will ask a series of questions and will provide a list of troubleshooting steps to perform, depending on the symptom.

Shoptalk

Possible causes are:

- Incorrect vessel personality file
- Customer interface box (C.I.B.)
- Original equipment manufacutrer (OEM) sensors.

Troubleshooting Summary

STEPS		SPECIFICATIONS
STEP 1.	Check the ED-4 display.	
	STEP 1A. Check for active fault code.	Fault or alarm code active?
	STEP 1B. Check vessel personality file.	Vessel personality file correct for this vessel?
	STEP 1C. Check the sensor connections.	All sensors and connections installed properly?
STEP 2.	Check the C.I.B.	
	STEP 2A. Check the sensor setup in the ED-4 display.	Approximately 5 volts?

STEP 1. Check the ED-4 display.

STEP 1A. Check for active fault code.

Conditions :

- Turn enable switch ON.

Action	Specification/Repair	Next Step
Check for fault code. • Check if fault is active in Advanced fault screen.	Fault or alarm code active? YES	Go to appropriate troubleshooting tree or refer to procedure mentioned in fault code description on the Advanced Fault screen.
	Fault or alarm code active? NO	1B

STEP 1B. Check vessel personality file.

Conditions :

- Turn enable switch ON.

Action	Specification/Repair	Next Step
Check vessel personality file. • Verify correct vessel personality file is downloaded in the display. Refer to Procedure 015-044 in Section 15. (/qs3/pubsys2/xml/en/procedures/513/513-015-044.html)	Vessel personality file correct for this vessel? YES	1C
	Vessel personality file correct for this vessel? NO Repair : Download correct vessel personality file to the display from Cummins QuickServe® Online. Refer to Procedure 015-044 in Section 15. (/qs3/pubsys2/xml/en/procedures/513/513-015-044.html)	Repair complete

STEP 1C. Check the sensor connections.

Conditions :

- Turn enable switch OFF.

Action	Specification/Repair	Next Step
Check connections. Inspect sensor, harness, and terminal block connections on OEM sensor wiring harness.	All sensor and connections installed properly? YES	2A
	All sensor and connections installed properly? NO Repair : Repair or fix connections or installation.	Repair complete

STEP 2. Check the C.I.B.

STEP 2A. Check the sensor setup in the ED-4 display.

Conditions :

- Turn enable switch OFF.
- Disconnect the OEM sensor wiring harness from the C.I.B.

Action	Specification/Repair	Next Step
--------	----------------------	-----------

Check voltage. - Place one lead on sensor SUPPLY pin 1 on the C.I.B. connector (mating to the OEM sensor harness). - Place the other lead on sensor RETURN pin 2 on the C.I.B. connector (mating to the OEM sensor harness).	Approximately 5 volts? YES Repair : Repair or replace the OEM sensor wiring harness. Refer to Procedure 015-103 in Section 15. (/qs3/pubsys2/xml/en/procedures/513/513-015-103.html)	Repair complete
Refer to the circuit diagram or wiring diagram for connector pin identification. Use the following procedure for general multimeter usage techniques. Refer to Procedure 019-359 in Section 19. (/qs3/pubsys2/xml/en/procedures/99/99-019-359.html)	Approximately 5 volts? NO Repair : Replace the C.I.B. Refer to Procedure 015-023 in Section 15. (/qs3/pubsys2/xml/en/procedures/513/513-015-023.html)	Repair complete