

Trainings ▾

Remove

Mark the flange to show oil hole orientation.

Remove the four capscrews, the thrust retainer plate, and the thrust bearings on the left-bank hydraulic pump drive idler gear.

Remove the hydraulic pump drive idler gear.

Remove the idler shaft.

