

Trainings ▾

Install

Install the fuel control valve body gasket.

Install the fuel control valve body assembly and mounting capscrews.

Tighten the mounting capscrews.

Torque Value: 45 n•m [33 ft-lb]

