

Trainings ▾

Remove

Remove the capscrews (1), cover plates (2), and gaskets (3) from the oil pan adapter (4).

