

Trainings ▾

Remove

There are different lubricating oil suction tube arrangements depending on the oil pan style.

Remove the nuts (5), capscrews (4), and strap (3) from the vertical support bracket assembly (2).

Remove the capscrews (8) and remove the vertical support bracket assembly.

Remove the three capscrews (6), and the oil suction tube (1).

