

Trainings ▾

Remove with Mechanically Actuated Injector

Remove the six capscrews.

Lightly tap on the end of the shaft with a rubber mallet, and remove the water pump drive assembly.

Remove, inspect, and discard the gasket, if damaged.

