

Trainings ▾

General Information

A QSk45 and QSK60 air starting motor is shown in the illustration.

The air starting motor system (tanks, line sizes, and valves) is designed and installed by the OEM and the starting motor suppliers. Refer any questions about the air starting systems to the manufacturer.

Do **not** operate the air starting motor with air pressure lower than 480 kPa [70 psi].

Maintain the air compressor according to the recommendations outlined in the component manufacturer's manual.

For maximum efficiency, the hoses, tubes, and lines **must not** leak.

Refer to the OEM and starting motor manufacturer's manuals for specific information regarding the starting motors, valves, and systems.

