

Trainings ▾

General Information

The air starting motor system (tanks, line sizes, and valves) is designed and installed by the original equipment manufacturer and the starting motor supplier. Refer any questions about the air starting systems to the manufacturer.



Maintenance Check

Do **not** operate the air starting motor with air pressure lower than 480 kPa [70 psi].

Maintain the air compressor according to the recommendations outlined in the manual.

For maximum efficiency, the hoses, tubes, and lines **must not** leak.

Refer to the original equipment manufacturer and starting motor manufacturer manuals for specific information regarding the starting motors, valves, and systems.

