

Trainings ▾

Voltage Check

Check the voltage of the OEM public datalink connector. The location of the datalink connector will depend on your engine type.

Refer to Procedure 019-026 in the troubleshooting and repair manual (electronic control system) for the appropriate engine type.

