



Technical Service Bulletin

Technical Service Bulletin: tsb101633

Released Date: 19-Apr-2005

Air Compressor Installation Procedure

Air Compressor Installation Procedure

Warranty Statement

The information in this document has no effect on present warranty coverage or repair practices, nor does it authorize TRP or Campaign actions.

Contents

This Service/Parts Topic updates the procedure for installing the air compressor on Signature, ISX, and QSX15 engines.

When installing an air compressor, Loctite™ 242, Part Number 3824040 or equivalent, **must** be used on capscrews which mount the air compressor to the gear housing. This seals the threads in the housing.

To evenly distribute the sealant as the capscrew is torqued, a line of sealant should be placed along the length of the capscrew.

Note : This is a product improvement and not subject to campaign.

Related Procedures

10-012-014-tr
(/qs3/pubsys2/xml/en/procedures/10/10-012-014-tr.html)

Air Compressor
(/qs3/pubsys2/xml/en/procedures/10/10-012-014-tr.html)

Last Modified: 19-Apr-2005