

Trainings ▾

Specifications

CAUTION

Engine intake air must be filtered to prevent dirt and debris from entering the engine. If air intake piping is damaged or loose, unfiltered air will enter the engine and cause premature wear.

Automotive Applications

Maximum Temperature Rise between Ambient Air and Engine Air Inlet (ambient above 0°C [32°F])Maximum Inlet Restriction (clean filter) Normal-Duty ElementMaximum Inlet Restriction (dirty filter)	17°C [30°F] 250 mm H ₂ O [10 in H ₂ O] 635 mm H ₂ O [25 in H ₂ O]
Maximum Allowable Pressure Drop across Charge Air Cooler psi 14 kPa [2 psi]Hg (mercury) 102 mm Hg [4 in Hg]	
Four-Step Wastegate Controller Solenoid Resistance	7 to 8 ohms