

Trainings ▾

Remove

Remove the V-band clamp between the exhaust adapter pipe and the turbocharger.

Remove the V-band clamp between the exhaust adapter pipe and the OEM exhaust down-pipe.

Remove the adapter pipe assembly from engine.

Remove the gasket from each end and discard. Do **not** use a screwdriver or other sharp tool to remove the gaskets. This will damage the gasket seating area.

Remove the aftertreatment injector from the adapter pipe.

Refer to Procedure 011-042 in Section 11.

(/qs3/pubsys2/xml/en/procedures/101/101-011-042-tr.html)

