

FAULT CODE 111 - Engine Control Module Critical Internal Failure - Bad Intelligent Device or Component

Warnings and Cautions

CAUTION

To reduce the possibility of damaging a new engine control module (ECM), all other active fault codes must be investigated prior to replacing the ECM.

Troubleshooting Summary

STEPS		SPECIFICATIONS
STEP 1.	Check the ECM.	
	STEP 1A. Check the ECM.	Fault Code 111 inactive?
	STEP 1B. Check the inactive counts of Fault Code 111.	Less than 3 counts?
STEP 2.	Check ECM calibration and clear fault codes.	
	STEP 2A. Check if an ECM calibration update is available.	If a calibration update for this fault code is available, does the ECM contain that revision or higher?
	STEP 2B. Disable the fault code.	Fault code inactive?

STEP 1. Check the ECM.

STEP 1A. Check the ECM.

Conditions :

- Connect all components.

Action	Specification/Repair	Next Step
Check the ECM. • Turn the keyswitch OFF and wait 5 seconds. • Start the engine and let it idle for 1 minute.	Fault Code 111 inactive? YES	1B
	Fault Code 111 inactive? NO Repair : Replace the ECM. Refer to Procedure 019-031 in the Associated Procedures Table.	2A

STEP 1B. Check the inactive counts of Fault Code 111.

Conditions : • Turn the keyswitch ON.		
Action	Specification/Repair	Next Step
Check the inactive counts of Fault Code 111. • Use INSITE™ electronic service tool to read the inactive counts of Fault Code 111.	Less than 3 counts? YES	2
	Less than 3 counts? NO Repair : Replace the ECM. Refer to Procedure 019-031 in the Associated Procedures Table.	Repair complete.

STEP 2. Check ECM calibration and clear fault codes.

STEP 2A. Check if an ECM calibration update is available.

Conditions : • Connect all components. • Connect INSITE™ electronic service tool.		
Action	Specification/Repair	Next Step

Compare the ECM code and revision number in the ECM to the calibration revisions listed in the ECM Calibration Revision History for applicable changes related to this fault code. Use INSITE™ electronic service tool to find the present ECM code and revision number in the ECM. The ECM code and revision number are found in the Calibration Information section of System ID and Dataplate in Features and Parameters.	If a calibration update for this fault code is available, does the ECM contain that revision or higher? YES	2B
	If a calibration update for this fault code is available, does the ECM contain that revision or higher? NO Repair : If necessary, calibrate the ECM. Refer to Procedure 019-032 in Section 19. (/qs3/pubsys2/xml/en/procedures/105/105-019-032.html)	2B

STEP 2B. Disable the fault code.

Conditions : - Connect all components. - Connect INSITE™ electronic service tool.		
Action	Specification/Repair	Next Step
Disable and clear the fault code. Operate the engine within the "Conditions for Clearing the Fault Code" found in the Overview section of this troubleshooting procedure.	Fault code inactive? YES	Repair complete
	Fault code inactive? NO Repair : Return to the troubleshooting steps or contact a Cummins® Authorized Repair Location if all steps have been completed and checked again.	1A

Associated Procedures

Associated Procedures			
Procedure Title	Procedure Number	Service Model Name	Bulletin Number
Engine Control Module	Refer to Procedure 019-031 (/qs3/pubsys2/xml/en/procedures/336/336-019-031.html)	ISL8.9 CM2880 L112	4358493
Engine Control Module	Refer to Procedure 019-031 (/qs3/pubsys2/xml/en/procedures/164/164-019-031.html)	ISL9.5 CM2150 SN	4310608
Engine Control Module	Refer to Procedure 019-031 (/qs3/pubsys2/xml/en/procedures/209/209-019-031-tr.html)	ISB3.9 CM2220 B107	4310792
Engine Control Module	Refer to Procedure 019-031 (/qs3/pubsys2/xml/en/procedures/218/218-019-031.html)	QSB4.5 CM2150 B108	4326163
Engine Control Module	Refer to Procedure 019-031 (/qs3/pubsys2/xml/en/procedures/216/216-019-031.html)	QSB6.7 CM2150 B109	4326168
Engine Control Module	Refer to Procedure 019-031 (/qs3/pubsys2/xml/en/procedures/331/331-019-031.html)	QSB7 CM2880 B117	4358390
Engine Control Module	Refer to Procedure 019-031 (/qs3/pubsys2/xml/en/procedures/177/177-019-031-tr.html)	ISG11 CM2880 G106	4332695

Associated Procedures			
Procedure Title	Procedure Number	Service Model Name	Bulletin Number
Engine Control Module	Refer to Procedure 019-031 (/qs3/pubsys2/xml/en/procedures/177/177-019-031-tr.html)	ISG12 CM2880 G107	4332690
Engine Control Module	Refer to Procedure 019-031 (/qs3/pubsys2/xml/en/procedures/325/325-019-031-tr.html)	ISG11 CM2880 G108	4332901
Engine Control Module	Refer to Procedure 019-031 (/qs3/pubsys2/xml/en/procedures/325/325-019-031-tr.html)	ISG12 CM2880 G109	4332906
Engine Control Module	Refer to Procedure 019-031 (/qs3/pubsys2/xml/en/procedures/206/206-019-031-tr.html)	QSNT14 CM876 N102	4325993
Engine Control Module	Refer to Procedure 019-031 (/qs3/pubsys2/xml/en/procedures/284/284-019-031-tr.html)	QSF2.8 CM2880 F104	4332741
Engine Control Module	Refer to Procedure 019-031 (/qs3/pubsys2/xml/en/procedures/284/284-019-031-tr.html)	QSF2.8 CM2880 F108	4332746
Engine Control Module	Refer to Procedure 019-031 (/qs3/pubsys2/xml/en/procedures/389/389-019-031-tr.html)	QSF3.8 CM2880 F112	4383825
Engine Control Module	Refer to Procedure 019-031 (/qs3/pubsys2/xml/en/procedures/383/383-019-031-tr.html)	ISB5.9 CM2880 B127	4383645

Associated Procedures			
Procedure Title	Procedure Number	Service Model Name	Bulletin Number
Engine Control Module	Refer to Procedure 019-031 (/qs3/pubsys2/xml/en/procedures/387/387-019-031.html)	ISF3.8 CM2220 F116	4383664
Engine Control Module	Refer to Procedure 019-031 (/qs3/pubsys2/xml/en/procedures/379/379-019-031.html)	ISB/ISD6.7 CM2880 B126	4383693
Engine Control Module	Refer to Procedure 019-031 (/qs3/pubsys2/xml/en/procedures/403/403-019-031.html)	QSL9.3 CM2880 L113	4383811
Engine Control Module	Refer to Procedure 019-031 (/qs3/pubsys2/xml/en/procedures/436/436-019-031.html)	QSC8.3 CM2880 C102	4388785
Engine Control Module	Refer to Procedure 019-031 (/qs3/pubsys2/xml/en/procedures/451/451-019-031.html)	QSB5.9 CM2880 B139	4388870
Engine Control Module	Refer to Procedure 019-031 (/qs3/pubsys2/xml/en/procedures/449/449-019-031.html)	QSB3.9 CM2880 B138	5411050
Engine Control Module	Refer to Procedure 019-031 (/qs3/pubsys2/xml/en/procedures/506/506-019-031.html)	ISD6.7 CM2880 D101	5411372
Engine Control Module	Refer to Procedure 019-031 (/qs3/pubsys2/xml/en/procedures/497/497-019-031.html)	ISF2.8 CM2220 F129	5411325

Associated Procedures			
Procedure Title	Procedure Number	Service Model Name	Bulletin Number
Engine Control Module	Refer to Procedure 019-031 (/qs3/pubsys2/xml/en/procedures/501/501-019-031.html)	ISF4.5 CM2220 F123	5411320
Engine Control Module	Refer to Procedure 019-031 (/qs3/pubsys2/xml/en/procedures/417/417-019-031.html)	QSG12 CM2880 G112	4388731
Engine Control Module	Refer to Procedure 019-031 (/qs3/pubsys2/xml/en/procedures/556/556-019-031.html)	ISF3.8 CM2220 F134B	5504165
Engine Control Module	Refer to Procedure 019-031 (/qs3/pubsys2/xml/en/procedures/577/577-019-031.html)	Z14 CM2670 Z103B	5504577
Engine Control Module	Refer to Procedure 019-031 (/qs3/pubsys2/xml/en/procedures/546/546-019-031.html)	D6.7 CM2670 D102B	5504515
Engine Control Module	Refer to Procedure 019-031 (/qs3/pubsys2/xml/en/procedures/629/629-019-031.html)	B6.2 CM2670 B156B	5579510
Engine Control Module	Refer to Procedure 019-031 (/qs3/pubsys2/xml/en/procedures/624/624-019-031.html)	X12 CM2670 X121B	5504455
Engine Control Module	Refer to Procedure 019-031 (/qs3/pubsys2/xml/en/procedures/622/622-019-031.html)	L9 CM2670 L128B	5504589

