

Trainings ▾

General Information

Follow the Normal Starting Procedure in this section. The engine will **not** start until the minimum lubricating oil pressure during cranking is detected by the engine control module (ECM). The engine can take more cranking time to start after an extended shut down or lubricating oil change. The engine will **only** run at idle until the minimum specified engine lubricating oil pressure is detected by the ECM.