

FAULT CODE 1852 - Water in Fuel Indicator

- Data Valid But Above Normal Operating Range - Moderately Severe Level

Troubleshooting Summary

STEPS		SPECIFICATIONS
STEP 1.	Check the fault codes.	
	STEP 1A. Check the fault codes.	Active or inactive counts of Fault Code 1852?
STEP 2.	Check the engine control module (ECM) calibration and clear the fault codes.	
	STEP 2A. Check if an ECM calibration update is available.	If a calibration update for this fault code is available, does the ECM contain that revision or higher?
	STEP 2B. Disable the fault code.	Fault code inactive?

STEP 1. Check the fault codes.

STEP 1A. Check the fault codes.

Conditions :

- Turn keyswitch ON.
- Connect the recommended Cummins® electronic service tool, or equivalent.

Action	Specification/Repair	Next Step
--------	----------------------	-----------

Check for Fault Code 1852. • Use the electronic service tool to read the fault codes.	Active or inactive counts of Fault Code 1852? YES Repair : Drain water from the fuel filter(s). If the fault code persists, check the sensor and harness connector for water intrusion. Clean or replace the connector or sensor, as necessary.	2A
	Active or inactive counts of Fault Code 1852? NO	Repair complete.

STEP 2 . Check the ECM calibration and clear the fault codes.

STEP 2A. Check if an ECM calibration update is available.

Conditions :

- Connect all components.
- Connect the electronic service tool.

Action	Specification/Repair	Next Step
--------	----------------------	-----------

Compare the ECM code and revision number in the ECM to the calibration revisions listed in the ECM Calibration Revision History for applicable changes related to this fault code. Use the electronic service tool to find the present ECM code and revision number in the ECM. The ECM code and revision number are found in the Calibration Information section of System ID and Dataplate in Features and Parameters.	If a calibration update for this fault code is available, does the ECM contain that revision or higher? YES	2B
	If a calibration update for this fault code is available, does the ECM contain that revision or higher? NO Repair : If necessary, calibrate the ECM. Refer to Procedure 019-032 in Section 19. (/qs3/pubsys2/xml/en/procedures/105/105-019-032.html)	2B

STEP 2B. Disable the fault code.

Conditions :

- Connect all components.
- Connect the electronic service tool.

Action	Specification/Repair	Next Step
Disable and clear the fault code. Operate the engine within the "Conditions for Clearing the Fault Code" found in the Overview section of this troubleshooting procedure.	Fault code inactive? YES	Repair complete.
	Fault code inactive? NO Repair : Return to the troubleshooting steps or contact a Cummins® Authorized Repair Location if all steps have been completed and checked again.	1A

