

FAULT CODE 5633 - Marine Low Load Protection - Condition Exists

Troubleshooting Summary

STEPS		SPECIFICATIONS
STEP 1.	Check the fault codes.	
	STEP 1A. Read the fault codes.	Fault Code 5633 active?
STEP 2.	Check engine control module (ECM) calibration and clear fault codes.	
	STEP 2A. Check if an ECM calibration update is available.	If a calibration update for this fault code is available, does the ECM contain that revision or higher?
	STEP 2B. Disable the fault code.	Fault code inactive?

STEP 1. Check the fault codes.

STEP 1A. Read the fault codes.

Conditions :

- Turn keyswitch ON.
- Connect INSITE™ electronic service tool.

Action	Specification/Repair	Next Step
--------	----------------------	-----------

Check for Fault Code 5633. • Use INSITE™ electronic service tool to read the fault codes. • Check for other active fault codes.	Fault Code 5633 active? YES Repair : This is an information-only fault code that will only become active if the engine torque exceeds the overload threshold for a calibratable time. Troubleshoot all other active fault codes. This fault code will become inactive when all other active fault codes are resolved.	2A
	Fault Code 5633 active? NO	

STEP 2. Check ECM calibration and clear fault codes.

STEP 2A. Check if an ECM calibration update is available.

Conditions :

- Connect all components.
- Connect INSITE™ electronic service tool.

Action	Specification/Repair	Next Step

Compare the ECM code and revision number in the ECM to the calibration revisions listed in the ECM Calibration Revision History for applicable changes related to this fault code. Use INSITE™ electronic service tool to find the present ECM code and revision number in the ECM. The ECM code and revision number are found in the Calibration Information section of System ID and Dataplate in Features and Parameters.	If a calibration update for this fault code is available, does the ECM contain that revision or higher? YES	2B
	If a calibration update for this fault code is available, does the ECM contain that revision or higher? NO Repair : If necessary, calibrate the ECM. Refer to Procedure 019-032 in Section 19. (/qs3/pubsys2/xml/en/procedures/105/105-019-032.html)	2B

STEP 2B. Disable the fault code.

Conditions : - Connect all components. - Connect INSITE™ electronic service tool.		
Action	Specification/Repair	Next Step
Disable and clear the fault code. Operate the engine within the "Conditions for Clearing the Fault Code" found in the Overview section of this troubleshooting procedure.	Fault code inactive? YES	Repair complete
	Fault code inactive? NO	Follow the technical escalation process.

