

Trainings ▾

General Information

ECM calibrations can be performed by the electronic software database and network.

©Cummins Inc.



19800902

The ECM calibration process for the engine occurs with the Run/Stop switch in the Stop position. **Always** follow the instructions on the service tool screens.

Note : If the tool will **not** communicate, disconnect the service harness, and reconnect it again to make sure all connections are good.

©Cummins Inc.



19600070

Connect the electronic service tool to the service tool datalink, which is located on the engine.

©Cummins Inc.



19800902

Refer to the INPOWER™ user's manual for detailed ECM calibration procedures.

©Cummins Inc.



19800902

