



Trainings ▾

Initial Check

Inspect the fuel shutoff solenoid post for extra wires that are possibly connected to supply power to another device. Remove the extra wires that are found connected to the solenoid post.




Check that the terminal post is **not** in contact with any metallic object other than the harness terminal. Turning the Run/Stop switch to Run signals the ECM to open the fuel shutoff solenoid valve. The solenoid closes when the ECM senses the Run/Stop switch is set to Stop or when the ECM senses an engine protection condition.




Resistance Check


The fuel shutoff valve is a two-post solenoid. Therefore, it has both a signal wire and a ground wire through the harness to the ECM. Disconnect the fuel shutoff valve solenoid terminals from the terminal posts. Check for damaged terminals.



Disconnect the engine harness from the extension harness. Check for damaged pins.




Disconnect the extension harness from the ECM. Check for damaged pins.



⚠ CAUTION ⚠

Do not use probes or leads other than Part Number 3822917. The connector will be damaged. The leads must fit tightly in the connector without expanding the pins of the connector.




Insert a test lead into the fuel shutoff valve signal pin at the extension harness. Connect the alligator clip to the multimeter probe.

Touch the other multimeter lead to the fuel shutoff valve signal terminal. Measure the resistance. The multimeter **must** show a closed circuit (10 ohms or less). If the circuit is **not** closed, repeat this procedure at the engine harness connector. If it still does **not** show a closed circuit, repair or replace the engine harness. Refer to Procedures 019-197

(/qs3/pubsys2/xml/en/procedures/99/99-019-197.html), 019-199 (/qs3/pubsys2/xml/en/procedures/99/99-019-199.html), 019-219 (/qs3/pubsys2/xml/en/procedures/99/99-019-219.html), and 019-043

(/qs3/pubsys2/xml/en/procedures/01/01-019-043.html). If the test at the engine harness shows a closed circuit, repair or replace the extension harness. Refer to Procedures 019-219 (/qs3/pubsys2/xml/en/procedures/99/99-019-219.html), 019-213 (/qs3/pubsys2/xml/en/procedures/99/99-019-213.html), and 019-175 (/qs3/pubsys2/xml/en/procedures/01/01-019-175.html). If the circuit is closed, it **must** still be checked for a short to ground and a short from pin to pin.




Insert a test lead into the fuel shutoff valve return pin at the extension harness. Connect the alligator clip to the multimeter probe.

Touch the other multimeter lead to the fuel shutoff valve return terminal. Measure the resistance. The multimeter **must** show a closed circuit (10 ohms or less). If the circuit is **not** closed, repeat this procedure at the engine harness connector. If it still does **not** show a closed circuit, repair or replace the engine harness. Refer to Procedures 019-197


(/qs3/pubsys2/xml/en/procedures/99/99-019-197.html), 019-199 (/qs3/pubsys2/xml/en/procedures/99/99-019-199.html), 019-219 (/qs3/pubsys2/xml/en/procedures/99/99-019-219.html), and 019-043

(/qs3/pubsys2/xml/en/procedures/01/01-019-043.html). If the test at the engine harness shows a closed circuit, repair or replace the extension harness. Refer to Procedure 019-219 (/qs3/pubsys2/xml/en/procedures/99/99-019-219.html), 019-213 (/qs3/pubsys2/xml/en/procedures/99/99-019-213.html), and 019-175 (/qs3/pubsys2/xml/en/procedures/01/01-019-175.html). If the circuit is closed, it **must** still be checked for a short to ground and a short from pin to pin.



Check for Short Circuit to Ground


Insert the electrical lead into the fuel shutoff valve signal at the engine harness connector pin. Touch the other multimeter probe to engine block. The ring terminal at the solenoid **must** be disconnected and can **not** touch anything that is grounded. Measure the resistance. The multimeter **must** show an open circuit (more than 100K ohms). If the circuit is **not** open, there is a short to ground in the fuel shutoff value signal wire. Repair or replace the engine harness. Refer to Procedures 019-197 (/qs3/pubsys2/xml/en/procedures/99/99-019-197.html), 019-199 (/qs3/pubsys2/xml/en/procedures/99/99-019-199.html), 019-219 (/qs3/pubsys2/xml/en/procedures/99/99-019-219.html), and 019-043 (/qs3/pubsys2/xml/en/procedures/01/01-019-043.html).



Check for Short Circuit from Pin to Pin


Check for a short circuit from the fuel shutoff valve signal pin to all other pins in the engine harness connector. Connect a test lead from the fuel shutoff valve signal pin in the engine harness connector. Connect the alligator clip of a second test lead to the other multimeter probe. Insert the pin of the lead into all of the other pins in the actuator.

The ring terminals at the solenoid **must** be disconnected and can **not** touch anything that is grounded. The battery voltage supply **must** be disconnected.




Measure the resistance. The multimeter **must** show an open circuit (more than 100k ohms). If the circuit is **not** open, there is a short between the fuel shutoff valve signal pin and **any** pin that measured a closed circuit. Repair or replace the engine harness. Refer to Procedures 019-197

(/qs3/pubsys2/xml/en/procedures/99/99-019-197.html), 019-199 (/qs3/pubsys2/xml/en/procedures/99/99-019-199.html), 019-219 (/qs3/pubsys2/xml/en/procedures/99/99-019-219.html), and 019-043 (/qs3/pubsys2/xml/en/procedures/01/01-019-043.html).




Repeat the above steps at the extension harness. If the circuit is **not** open, there is a short between the fuel shutoff valve signal pin and **any** pin that measured a closed circuit. Repair or replace the extension harness. Refer to Procedures 019-219 (/qs3/pubsys2/xml/en/procedures/99/99-019-219.html), 019-213 (/qs3/pubsys2/xml/en/procedures/99/99-019-213.html), and 019-175 (/qs3/pubsys2/xml/en/procedures/01/01-019-175.html).



Check for Short Circuit to External Voltage Source

Check for a short circuit from the fuel shutoff valve circuit to a +12 VDC source. Disconnect the extension harness connector from the ECM. Connect the battery voltage supply if it has been disconnected. Set the Run/Stop switch to the Run position. Adjust the multimeter to measure VDC. Insert a test lead into the fuel shutoff valve signal pin; connect it to the multimeter. Touch the other multimeter probe to the engine block ground.



Note : An external voltage source is **any** wire in the OEM wiring that carries voltage.

Measure the voltage. The voltage **must** be 1.5 VDC or less. If the voltage is **not** correct, there is a short circuit between the fuel shutoff valve circuit and an external voltage source. Remove the external voltage source.

Connect all components after the repair is complete.

