

Trainings ▾

General Information

INPOWER™ is a service tool for the generator-drive control system. Use INPOWER™ to:

- Program owner-specified information into the ECM (parameters and features)
- Aid in troubleshooting the engine
- Change the engine power or rated speed calibration

Refer to INPOWER™ manual for specifics.



INPOWER™ Adjust Mode

The adjustment feature allows you to make adjustments to genset parameters for trims and settings. There are several adjustment parameters and not all gensets will have the same adjustments available.

©Cummins Inc.

INPOWER™ Monitor Mode

The INPOWER™ monitor mode is a useful troubleshooting aid that displays the key ECM inputs and outputs. This feature can be used to spot constant or abnormally fluctuating values.

The ECM inputs show the data that is being fed into the ECM by the system's sensors and switches. The ECM outputs are values that the ECM commands to the generator-drive control

©Cummins Inc.

system. Monitor mode allows the relationship between the ECM inputs and outputs to be monitored and used during troubleshooting.

INPOWER™ PRO Description

INPOWER™ PRO allows user to transfer new or updated calibration files for the generator-drive control system ECM from a central location to Cummins distributors. A calibration file is electronic data that give the engine its performance rating.

©Cummins Inc.

The calibration file will be loaded into INPOWER™, which is then used to load the file into the ECM.

Refer to your Cummins service representative and the INPOWER™ manual for more information.

©Cummins Inc.



19800902

INPOWER™ Test Mode

The test feature is a diagnostic tool that is used to perform internal self-checks on the PowerCommand Control to verify inputs and outputs of the control system and test engine protection functions.

©Cummins Inc.

