

Trainings ▾

Torque Table

Holset® SS191 A/C Model

Assembly Torque Specifications			
Component	N•m	ft-lb	in-lb
Bearing Capscrews	16		142
Bottom Cover Plate Capscrews	16		142
Connecting Rod Capscrews	25	18	
Cylinder Block to Crankcase Capscrews	a. 20	15	
	b. 41	30	
Cylinder Head Capscrews	a. 30	22	
	b. 41	30	
Exhaust Valve Seat	108	80	
Inlet Cage	108	80	
Power Steering Coupling to Crankshaft Capscrew	23	17	
Unloader Cover	41	30	

Holset® QE230, QE296, and QE338 A/C Model

Assembly Torque Specifications			
Component	N•m	ft-lb	in-lb
Crankshaft Pipe Plug (Steps 1, 2, and 3)	(1) 8		70
	(2) 17	13	
	(3) 20	15	
Support to Crankcase Captive Washer Capscrews (Step 4)	(4) 47	35	

Assembly Torque Specifications			
Component	N•m	ft-lb	in-lb
Cover and Head to Crankcase Hexagon Head Capscrews (All SS Models)	27	20	
Unloading Valve Body to Cover Captive Washer Capscrews (All SS Models)	15	11	
Hydraulic Pump Adapter to Crankcase Capscrews	60	45	
Drive Gear Retaining Capscrew	100	75	
Head Hexagon Head Capscrews (All QE Models) (Center Capscrew)	(1) 14	10	
	(2) 28	21	
Head Hexagon Head Capscrews (All QE Models) (Center Capscrew)	28	21	
Unloading Valve Body	27	20	

Holset® ST676 A/C Model

Assembly Torque Specifications			
Component	N•m	ft-lb	in-lb
Cover to Crankcase Capscrews	47	35	
Cap to Connecting Rod Capscrews	23	17	
Cylinder Head Capscrews	41	30	
Support to Crankcase Capscrews	47	35	

Assembly Torque Specifications			
Component	N•m	ft-lb	in-lb
Unloading Valve Bodies to Cover Capscrews	14	10	
Pipe Plugs			
[1/16 in]	14	10	
[1/8 in]	20	15	
[1/4 in]	25	20	
[3/8 in]	35	25	
[1/2 in]	55	40	
[3/4 in]	75	55	

Holset® ST773 A/C Model

Assembly Torque Specifications			
Component	N•m	ft-lb	in-lb
Cover to Crankcase Capscrews	47	35	
Cap to Connecting Rod Capscrews	23	17	
Cylinder Head Capscrews	41	30	
Support to Crankcase Capscrews	47	35	
Unloading Valve Bodies to Cover Capscrews	14	10	
Pipe Plugs			
[1/16 in]	14	10	
[1/8 in]	20	15	
[1/4 in]	25	20	
[3/8 in]	35	25	
[1/2 in]	55	40	
[3/4 in]	75	55	

