

## Trainings ▾

### Maintenance Check

**Note :** Depending on application, all engines will possibly not be equipped with an air compressor.

Inspect the compressor housing for cracks and damage.

Inspect the hydraulic pump couplings for cracks, wear, or damage (if equipped).

Inspect the air plumbing for splits or cracks.

Inspect the air compressor mounting nuts, including support bracket, for loose or damaged hardware.

Operate the engine and check for correct compressor operation and air, oil, and coolant leaks.

**Torque Value:**

Mounting 18 mm 77 n•m [ 57 ft-lb ]

**Torque Value:**

Bracket 10 mm 45 n•m [ 33 ft-lb ]

