

Trainings ▾

Install

Install the alternator pulley.

Install and tighten the alternator pulley mounting nut.

Torque Value: 80 n•m [59 ft-lb]

