

Trainings ▾

General Information

Follow the Normal Starting Procedure in this section. The engine will run at idle **only** until the minimum specified oil pressure is detected by the engine control module (ECM).

Last Modified: 14-Oct-2016
