

Trainings ▾

Maintenance Check

If the air compressor inlet is plumbed to the engine intake air system downstream of the engine intake air filter, an air compressor air cleaner element will **not** be present.

If the air compressor is equipped with an air filter, replace the filter at 250 hours or 6 months.

