

Starter Does Not Disengage

Symptoms

- The engine continues to crank after the operator pushed the start button on the engine room panel or remote panel.

How To Use This Tree

This symptom tree can be used to troubleshoot engine start symptoms. Start by performing Step 1 troubleshooting. Step 2 will ask a series of questions and will provide a list of troubleshooting steps to perform depending on the symptom.

Shoptalk

Troubleshooting Summary

STEPS		SPECIFICATIONS
STEP 1.	Check Customer Interface Box	
	STEP 1A. Check Customer Interface Box Logic Unit	Is crank lamp illuminated?

STEP 1. Check Customer Interface Box

STEP 1A. Check Customer Interface Box Logic Unit

Conditions :

- Locate customer interface box
- Open customer interface box.

Action	Specification/Repair	Next Step

Verify crank lamp is illuminated on customer interface box logic unit.	Is crank lamp illuminated? YES Repair : Refer to the Un-requested Engine Start troubleshooting tree.	Repair complete.
	Is crank lamp illuminated? NO Repair : Refer to Procedure 013-020 (/qs3/pubsys2/xml/en/procedures/20/20-013-020-tr.html) in the QSK19 and QSK19 CM850 Modular Common Rail System Series Engines, Bulletin 4021592.	Repair complete.