

# Un-requested Engine Stop

## Symptoms

- The engine stops without the operator pushing the stop button on the engine room panel or remote panel.

## How To Use This Tree

This symptom tree can be used to troubleshoot engine stop symptoms. Start by performing Step 1 troubleshooting. Step 2 will ask a series of questions and will provide a list of troubleshooting steps to perform depending on the symptom.

## Shoptalk

## Troubleshooting Summary

| STEPS   |                                                  | SPECIFICATIONS                |
|---------|--------------------------------------------------|-------------------------------|
| STEP 1. | Check Customer Interface Box                     |                               |
|         | STEP 1A. Check Customer Interface Box Logic Unit | Is stop lamp illuminated?     |
| STEP 2. | Check Engine Room Panel                          |                               |
|         | STEP 2A. Check Engine Room Panel Control Panel   | Less than 10 ohms resistance? |
| STEP 3. | Check Remote Panel                               |                               |
|         | STEP 3A. Check Remote Panel Control Panel        | Less than 10 ohms resistance? |

## STEP 1. Check Customer Interface Box

### STEP 1A. Check Customer Interface Box Logic Unit

**Conditions :**

- Locate customer interface box
- Open customer interface box.

| Action                           | Specification/Repair                                                                                                                                     | Next Step               |
|----------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------|
| Verify stop lamp is illuminated. | Is stop lamp illuminated?<br><b>YES</b>                                                                                                                  | <b>2A</b>               |
|                                  | Is stop lamp illuminated?<br><b>NO</b><br><br><b>Repair :</b><br><br>Refer to the Engine<br>Executes Un-requested<br>Engine Stop<br>Troubleshooting Tree | <b>Repair complete.</b> |

## STEP 2. Check Engine Room Panel

### STEP 2A. Check Engine Room Panel Control Panel

**Conditions :**

- Locate engine room panel
- Open engine room panel door
- Disconnect control panel connector X4.

| Action | Specification/Repair | Next Step |
|--------|----------------------|-----------|
|--------|----------------------|-----------|

|                                                                                                                                                                                                                                                                                                                      |                                                                                                                                                                                                                            |                                |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------|
| <p>Check the engine room panel control panel.</p> <ul style="list-style-type: none"> <li>Place one test lead in the engine room panel stop supply pin on the control panel X4 connector.</li> <li>Place the other test lead in the engine room power switch supply pin on the control panel X4 connector.</li> </ul> | <p>Less than 10 ohms resistance?</p> <p><b>YES</b></p> <p><b>Repair :</b></p> <p>Replace the engine room panel control panel.</p> <p>Refer to Procedure 015-024 (/qs3/pubsys2/xml/en/procedures/115/115-015-024.html).</p> | <p><b>Repair complete.</b></p> |
|                                                                                                                                                                                                                                                                                                                      | <p>Less than 10 ohms resistance?</p> <p><b>NO</b></p>                                                                                                                                                                      | <p><b>3A</b></p>               |

### STEP 3. Check Remote Panel

#### STEP 3A. Check Remote Panel Control Panel

| <p><b>Conditions :</b></p> <ul style="list-style-type: none"> <li>Locate remote panel</li> <li>Open remote panel</li> <li>Disconnect remote panel control panel connector X4.</li> </ul> |                      |           |
|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------|-----------|
| Action                                                                                                                                                                                   | Specification/Repair | Next Step |
| Empty space for content                                                                                                                                                                  |                      |           |

|                                                                                                                                                                                                                                                                                                             |                                                                                                                                                                                                                               |                                |
|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------|
| <p>Check the remote panel control panel.</p> <ul style="list-style-type: none"> <li>Place one test lead in the remote panel power switch supply pin on the control panel X4 connector.</li> <li>Place the other test lead on the remote panel stop supply pin of the control panel X4 connector.</li> </ul> | <p>Less than 10 ohms resistance?</p> <p><b>YES</b></p> <p><b>Repair :</b></p> <p>Replace the remote control panel control panel.</p> <p>Refer to Procedure 015-025 (/qs3/pubsys2/xml/en/procedures/115/115-015-025.html).</p> | <p><b>Repair complete.</b></p> |
|                                                                                                                                                                                                                                                                                                             | <p>Less than 10 ohms resistance?</p> <p><b>NO</b></p> <p><b>Repair :</b></p> <p>Replace customer interface box logic unit.</p> <p>Refer to Procedure 015-023 (/qs3/pubsys2/xml/en/procedures/115/115-015-023.html).</p>       | <p><b>Repair complete.</b></p> |