

Engine Will Not Stop From the Engine Room or Remote Panel

Symptoms

- Engine will **not** stop when the stop button is pushed at the engine room panel.
- Engine will **not** stop when the stop button is pushed at the remote panel.

How To Use This Tree

This symptom tree can be used to troubleshoot engine stop symptoms. Start by performing Step 1 troubleshooting. Step 2 will ask a series of questions and will provide a list of troubleshooting steps to perform, depending on the symptom.

Shoptalk

The engine can be stopped by pushing the stop button from the engine room panel or remote panel. The panel does **not** need to have start control to stop the engine.

Troubleshooting Summary

STEPS		SPECIFICATIONS
STEP 1.	Check Engine Room Panel Stop Button	
	STEP 1A. Check Stop Button Input to Customer Interface Box Logic Unit	Stop lamp illuminated?
	STEP 1B. Check Stop Button Operation	Less than 10 ohms resistance?
STEP 2.	Check Remote Panel Stop Button	
	STEP 2A. Check Stop Button to Customer Interface Box Logic Unit	Stop lamp illuminated?
	STEP 2B. Check Stop Button Operation	Less than 10 ohms resistance?
STEP 3.	Check Panel Wiring	
	STEP 3A. Check Engine Room Panel Wiring	Less than 10 ohms resistance?

STEPS		SPECIFICATIONS
	STEP 3A-1. Check Engine Room Power Switch Supply Wire	Less than 10 ohms resistance?
	STEP 3A-2. Check Engine Room Panel Stop Supply Wire	Less than 10 ohms resistance?
STEP 4.	Check Panel System Cables	
	STEP 4A. Check Engine Room Panel Cable	Less than 10 ohms resistance?
	STEP 4B. Check Remote Panel Cable	Less than 10 ohms resistance?
STEP 5.	Check Customer Interface Box Wiring	
	STEP 5A. Check Engine Room Panel Stop Supply Wire	Less than 10 ohms resistance?
	STEP 5B. Check the Remote Panel Stop Supply Wire	Less than 10 ohms resistance?

STEP 1. Check Engine Room Panel Stop Button

STEP 1A. Check Stop Button Input to Customer Interface Box Logic Unit

Conditions :

- Locate engine room panel
- Engine room panel power lamp illuminated
- Open customer interface box.

Action	Specification/Repair	Next Step
Check engine stop button input to customer interface box logic unit. • Push the stop button. • Verify stop lamp is illuminated on the customer interface box logic unit.	Stop lamp illuminated? YES	2A
	Stop lamp illuminated? NO	1B

STEP 1B. Check Stop Button Operation

Conditions :

- Open engine room panel
- Disconnect engine room panel cable connector from control panel.

Action	Specification/Repair	Next Step
Check the stop button operation. • Place one test lead on the engine room panel power switch supply terminal of the control panel connector. • Place the other test lead on the engine room panel stop supply terminal of the control panel connector. • Press the stop button.	Less than 10 ohms resistance? YES	3A
	Less than 10 ohms resistance? NO Repair : Replace the control panel. Refer to Procedure 015-024 (/qs3/pubsys2/xml/en/procedures/115/115-015-024.html).	Repair complete.

STEP 2. Check Remote Panel Stop Button

STEP 2A. Check Stop Button to Customer Interface Box Logic Unit

Conditions :

- Locate remote panel
- Remote panel power lamp illuminated
- Open customer interface box.

Action	Specification/Repair	Next Step

Check the engine stop button input to customer interface box logic unit. • Press the stop button. • Verify the stop lamp illuminated on the customer interface box logic unit.	Stop lamp illuminated? YES Repair : Replace the customer interface box logic unit. Refer to Procedure 015-023 (/qs3/pubsys2/xml/en/procedures/115/115-015-023.html).	Repair complete.
	Stop lamp illuminated? NO	2B

STEP 2B. Check Stop Button Operation

Conditions :

- Open remote panel
- Disconnect engine room panel cable connector from the control panel.

Action	Specification/Repair	Next Step
Check the stop button operation. • Place one test lead on the remote panel stop supply terminal of the control panel connector. • Place the other test lead on the remote panel power switch supply terminal of the control panel connector. • Press the stop button.	Less than 10 ohms resistance? YES	4B
	Less than 10 ohms resistance? NO Repair : Replace the control panel. Refer to Procedure 015-025 (/qs3/pubsys2/xml/en/procedures/115/115-015-025.html).	Repair complete.

STEP 3. Check Panel Wiring

STEP 3A. Check Engine Room Panel Wiring

Conditions :

- Locate engine room panel
- Open engine room panel door.

Action	Specification/Repair	Next Step
Check engine room panel wiring. • Disconnect cable C14 from the engine room panel. • Connect one test lead to the engine room power switch supply pin at the C14 connector. • Place the other test lead on the engine room panel stop supply pin at the C14 connector. • Press the stop button.	Less than 10 ohms resistance? YES	4A
	Less than 10 ohms resistance? NO	3A-1

STEP 3A-1. Check Engine Room Power Switch Supply Wire

Conditions :

- Locate engine room panel
- Open engine room panel door.

Action	Specification/Repair	Next Step
--------	----------------------	-----------

Check wires between harness connector and control panel connector. • Disconnect cable C14 from the engine room panel. • Place one test lead on the engine room power switch supply pin on connector C14. • Place the other test lead on the engine room power switch supply pin on the control panel connector.	Less than 10 ohms resistance? YES	3A-2
	Less than 10 ohms resistance? NO Repair : Replace the faulty wire. Refer to Procedure 015-024 (/qs3/pubsys2/xml/en/procedures/115/115-015-024.html).	Repair complete.

STEP 3A-2. Check Engine Room Panel Stop Supply Wire

Conditions : • Locate engine room panel • Open engine room panel door.		
Action	Specification/Repair	Next Step
Check wires between harness connector and control panel connector. • Disconnect cable C14 from the engine room panel. • Place one test lead on the engine room panel stop supply pin on the C14 connector. • Place the other test lead on the engine room panel stop supply pin on the control panel connector.	Less than 10 ohms resistance? YES	4A
	Less than 10 ohms resistance? NO Repair : Replace the faulty wire. Refer to Procedure 015-024 (/qs3/pubsys2/xml/en/procedures/115/115-015-024.html).	Repair complete.

STEP 4. Check Panel System Cables

STEP 4A. Check Engine Room Panel Cable

Conditions :

- Disconnect cable connector C14 from the engine room panel
- Disconnect cable connector C7 from the customer interface box.

Action	Specification/Repair	Next Step
Check engine room panel cable. • Install a jumper between engine room power switch supply pin and the engine room panel stop supply pin in connector C14. • Place one test lead in the engine room power switch supply pin in connector C7. • Place the other test lead in the engine room panel stop supply pin in connector C7.	Less than 10 ohms resistance? YES	5A
	Less than 10 ohms resistance? NO Repair : Replace the cable.	Repair complete.

STEP 4B. Check Remote Panel Cable

Conditions :

- Locate and open customer interface box
- Locate and open remote panel
- Disconnect remote panel cable from customer interface box X4 connector.

Action	Specification/Repair	Next Step
--------	----------------------	-----------

Check the remote panel cable. • Install a jumper between remote panel power switch supply terminal and remote panel stop supply terminal on remote control panel X4 in the remote control panel. • Place one test lead on the remote panel power switch supply wire. • Place the other test lead on the remote panel stop supply wire.	Less than 10 ohms resistance? YES	5B
	Less than 10 ohms resistance? NO Repair : Replace the cable.	Repair complete.

STEP 5. Check Customer Interface Box Wiring

STEP 5A. Check Engine Room Panel Stop Supply Wire

Conditions :

- Open the customer interface box
- Disconnect engine room cable at connector C7 from the customer interface box.

Action	Specification/Repair	Next Step

Check the engine room panel stop supply wire. - Place one test lead on the engine room panel stop supply pin in connector C7. - Place the other test lead on the engine room panel stop supply terminal on the customer interface box logic unit.	Less than 10 ohms resistance? YES	2A
	Less than 10 ohms resistance? NO Repair : Replace the faulty wire. Refer to Procedure 015-023 (/qs3/pubsys2/xml/en/procedures/115/115-015-023.html).	Repair complete.

STEP 5B. Check the Remote Panel Stop Supply Wire

Conditions :

- Open the customer interface box.

Action	Specification/Repair	Next Step
--------	----------------------	-----------

Check the remote panel stop supply wire. - Place one test lead on the remote panel stop supply wire terminal in the customer interface box X4 connector. - Place the other test lead on the remote panel stop supply wire terminal on the customer interface box logic unit.	Less than 10 ohms resistance? YES Repair : Replace the customer interface box logic unit. Refer to Procedure 015-023 (/qs3/pubsys2/xml/en/procedures/115/115-015-023.html).	Repair complete.
	Less than 10 ohms resistance? NO Repair : Replace the wire. Refer to Procedure 015-023 (/qs3/pubsys2/xml/en/procedures/115/115-015-023.html).	Repair complete.