

# Engine Does Not Respond to Engine Stop

## Symptoms

- The engine will **not** stop when the engine stop button is engaged at the customer interface box.

## How To Use This Tree

This symptom tree can be used to troubleshoot engine stop symptoms. Start by performing Step 1 troubleshooting. Step 2 will ask a series of questions and will provide a list of troubleshooting steps to perform, depending on the symptom.

## Shoptalk

## Troubleshooting Summary

| STEPS   |                                   | SPECIFICATIONS                |
|---------|-----------------------------------|-------------------------------|
| STEP 1. | Check Customer Interface Box      |                               |
|         | STEP 1A. Check Engine Stop Switch | Less than 10 ohms resistance? |

## STEP 1. Check Customer Interface Box

### STEP 1A. Check Engine Stop Switch

| <b>Conditions :</b> <ul style="list-style-type: none"><li>Open customer interface box.</li></ul> |                      |           |
|--------------------------------------------------------------------------------------------------|----------------------|-----------|
| Action                                                                                           | Specification/Repair | Next Step |

|                                                                                                                                                                                                                 |                                                                                                                                                                                                                                                                                                                                        |                                |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------|
| <p>Check engine stop switch.</p> <ul style="list-style-type: none"> <li>• Disconnect the four ignition (engine stop) wires from the button.</li> </ul>                                                          | <p>Less than 10 ohms resistance?</p> <p><b>YES</b></p> <p><b>Repair :</b></p> <p>Replace the engine stop button.</p> <p>Refer to Procedure 015-023 (/qs3/pubsys2/xml/en/procedures/115/115-015-023.html).</p>                                                                                                                          | <p><b>Repair complete.</b></p> |
| <ul style="list-style-type: none"> <li>• Place a test lead on each side of one contact of the button.</li> <li>• Push the engine stop button.</li> <li>• Repeat for the other contact of the button.</li> </ul> | <p>Less than 10 ohms resistance?</p> <p><b>NO</b></p> <p><b>Repair :</b></p> <p>Refer to Section TF in the Troubleshooting and Repair Manual, Electronic Control System, QSK19 CM850, Modular Common Rail System, Series Engines, Bulletin 4021493 (/qs3/portal/manualviewer.html?path=/qs3/pubsys2/xml/en/outlines/4021493.html).</p> | <p><b>Repair complete.</b></p> |