

Engine Room Panel Local/Remote Switch Does Not Switch to Local

Symptoms

- Engine will crank when the start button is pushed at the remote panel.

How To Use This Tree

This symptom tree can be used to troubleshoot engine start symptoms. Start by performing Step 1 troubleshooting. Step 2 will ask a series of questions and will provide a list of troubleshooting steps to perform, depending on the symptom.

Shoptalk

- To initiate engine crank from the engine room panel, the following panel parameters **must** be met:
- The engine room panel power switch on and lamp illuminated.
 - The engine **must** be stopped.
- To initiate engine crank from the remote panel, the following panel parameters **must** be met:
- The remote panel power lamp illuminated.
 - The local start **only** lamp is **not** illuminated.
 - The engine **must** be stopped.

Troubleshooting Summary

STEPS		SPECIFICATIONS
STEP 1.	Check the Customer Interface Box Logic Unit	
	STEP 1A. Check Local Mode Lamp	Is local mode lamp illuminated?
STEP 2.	Check Engine Room Panel	
	STEP 2A. Check Local Start Only Button	Less than 10 ohms resistance?
STEP 3.	Check Panel Wiring	

STEPS		SPECIFICATIONS
	STEP 3A. Check Engine Room Panel Wiring	Less than 10 ohms resistance?
	STEP 3A-1. Check Engine Room Power Switch Supply Wire	Less than 10 ohms resistance?
	STEP 3A-2. Check the Local Mode Supply Wire	Less than 10 ohms resistance?
STEP 4.	Check Panel System Cable	
	STEP 4A. Check Engine Room Panel Cable	Less than 10 ohms resistance?
STEP 5.	Check Customer Interface Box	
	STEP 5A. Check the Local Mode Supply Wire	Less than 10 ohms resistance?

STEP 1. Check Customer Interface Box Logic Unit

STEP 1A. Check Local Mode Lamp

Conditions :

- Locate engine room panel
- Power switch on and lamp illuminated
- Open customer interface box.

Action	Specification/Repair	Next Step
Check local mode lamp. • Push the local start only button. • Verify local mode lamp illuminated on the customer interface box logic unit.	Is the local mode lamp illuminated? YES	Repair complete.
	Is the local mode lamp illuminated? NO	2A

STEP 2. Check Engine Room Panel

STEP 2A. Check Local Start Only Button

Conditions :

- Locate engine room panel
- Disconnect control panel connector.

Action	Specification/Repair	Next Step
Verify local start only button function. • Place one test lead on the engine room power switch supply terminal of the control panel connector. • Place the other test lead on the local mode supply terminal of the control panel connector. • Press the local start only button.	Less than 10 ohms resistance? YES	3A
	Less than 10 ohms resistance? NO Repair : Replace the control panel. Refer to Procedure 015-024 (/qs3/pubsys2/xml/en/procedures/115/115-015-024.html).	Repair complete.

STEP 3. Check Panel Wiring

STEP 3A. Check Engine Room Panel Wiring

Conditions :

- Locate engine room panel
- Open engine room panel door.

Action	Specification/Repair	Next Step
--------	----------------------	-----------

Check engine room panel wiring. • Disconnect cable connector C14 from the engine room panel. • Connect one test lead to the engine room power switch supply pin at the C14 connector on the panel. • Place the other test lead on the local mode supply pin at the C14 connector on the panel. • Press the local start only button.	Less than 10 ohms resistance? YES	4A
	Less than 10 ohms resistance? NO	3A-1

STEP 3A-1. Check Engine Room Power Switch Supply Wire

Conditions :

- Locate engine room panel
- Open engine room panel door.

Action	Specification/Repair	Next Step
Check wires between harness connector and control panel connector. • Disconnect cable connector C14 from the engine room panel. • Place one test lead on the engine room power switch supply pin on panel connector C14. • Place the other test lead on the engine room power switch supply pin on the control panel connector.	Less than 10 ohms resistance? YES	3A-2
	Less than 10 ohms resistance? NO Repair : Replace the faulty wire. Refer to Procedure 015-024 (/qs3/pubsys2/xml/en/procedures/115/115-015-024.html).	Repair complete.

STEP 3A-2. Check the Local Mode Supply Wire

Conditions :

- Locate engine room panel
- Open engine room panel door.

Action	Specification/Repair	Next Step
Check wires between harness connector and control panel connector. • Disconnect cable connector C14 from the engine room panel. • Place one test lead on the local mode supply pin on connector C14. • Place the other test lead on the local mode supply pin on the control panel connector.	Less than 10 ohms resistance? YES	4A
	Less than 10 ohms resistance? NO Repair : Replace the faulty wire. Refer to Procedure 015-024 (/qs3/pubsys2/xml/en/procedures/115/115-015-024.html).	Repair complete.

STEP 4. Check Panel System Cable

STEP 4A. Check Engine Room Panel Cable

Conditions :

- Disconnect cable connector C14 from the engine room panel
- Disconnect cable connector C7 from the customer interface box.

Action	Specification/Repair	Next Step

Check the engine room panel cable. • Install a jumper between the engine room power switch supply pin and the local mode supply pin in connector C14. • Place one test lead in the engine room power switch supply pin in connector C7. • Place the other test lead in the local mode supply pin in connector C7.	Less than 10 ohms resistance? YES	5A
	Less than 10 ohms resistance? NO Repair : Replace the cable.	Repair complete.

STEP 5. Check Customer Interface Box Wiring

STEP 5A. Check the Local Mode Supply Wire

Conditions : • Open the customer interface box • Disconnect engine room cable at connector C7 from the customer interface box.		
Action	Specification/Repair	Next Step

Check the local mode supply wire. - Place one test lead on the local mode supply pin in connector C7. - Place the other test lead on the local mode supply terminal on the customer interface box logic unit.	Less than 10 ohms resistance? YES Repair : Replace the customer interface box logic unit. Refer to Procedure 015-023 (/qs3/pubsys2/xml/en/procedures/115/115-015-023.html).	Repair complete.
	Less than 10 ohms resistance? NO Repair : Replace the faulty wire. Refer to Procedure 015-023 (/qs3/pubsys2/xml/en/procedures/115/115-015-023.html).	Repair complete.