

Remote Panel Does Not Switch to Local

Symptoms

- Engine will crank when the start button is pushed at the remote panel.

How To Use This Tree

This symptom tree can be used to troubleshoot engine start symptoms. Start by performing Step 1 troubleshooting. Step 2 will ask a series of questions and will provide a list of troubleshooting steps to perform, depending on the symptom.

Shoptalk

- To initiate engine crank from the engine room panel the following panel parameters **must** be met:
- The engine room power switch on and lamp illuminated.
 - The engine **must** be stopped.
- To initiate engine crank from the remote panel the following panel parameters **must** be met:
- The remote panel power lamp illuminated.
 - The local start **only** lamp is **not** illuminated.
 - The engine **must** be stopped.

Troubleshooting Summary

STEPS		SPECIFICATIONS
STEP 1.	Check Customer Interface Box Logic Unit	
	STEP 1A. Check Local Mode Lamp	Is the local mode lamp illuminated?
	STEP 1B. Check Local Start Only Lamp at Remote Panel	Local start only lamp illuminated?
STEP 2.	Check Panel System Cable	
	STEP 2A. Check Remote Panel Cable	Less than 10 ohms resistance?
STEP 3.	Check Customer Interface Box Wiring	

STEPS		SPECIFICATIONS
	STEP 3A. Check the Remote Panel Local Mode Supply Wire	Less than 10 ohms resistance?

STEP 1. Check Customer Interface Box Logic Unit

STEP 1A. Check Local Mode Lamp

Conditions :

- Locate engine room panel
- Power switch on and lamp illuminated
- Open customer interface box.

Action	Specification/Repair	Next Step
Check local mode lamp. • Push the local start only button. • Verify local mode lamp illuminated on the customer interface box logic unit.	Is the local mode lamp illuminated? YES	1B
	Is the local mode lamp illuminated? NO Repair : Refer to Engine Room Panel Fails to Switch to Local symptom tree.	Repair complete.

STEP 1B. Check Local Start Only Lamp at Remote Panel

Conditions :

- Locate remote panel
- Power lamp illuminated.

Action	Specification/Repair	Next Step
--------	----------------------	-----------

Check local start only lamp.	Is local start only lamp illuminated? YES	Repair complete.
	Is local start only lamp illuminated? NO	2A

STEP 2. Check Panel System Cable

STEP 2A. Check Remote Panel Cable

Conditions :

- Locate and open customer interface box
- Locate and open remote panel.

Action	Specification/Repair	Next Step
Check the remote panel cable. • Install a jumper between remote panel local mode supply terminal and the remote panel return terminal on remote panel control panel connector. • Place one test lead on the remote panel local mode supply terminal in customer interface box X4 connector. • Place the other test lead on the remote panel return terminal in the customer interface box X4 connector.	Less than 10 ohms resistance? YES	3A
	Less than 10 ohms resistance? NO Repair : Replace the cable. Refer to the OEM service manual.	Repair complete.

STEP 3. Check Customer Interface Box Wiring

STEP 3A. Check the Remote Panel Local Supply Wire

Conditions :

- Open the customer interface box
- Disconnect remote panel cable at X4 connector of the customer interface box.

Action	Specification/Repair	Next Step
Check the remote panel local mode supply wire. • Place one test lead on the remote panel local mode supply pin in connector X4 of the customer interface box. • Place the other test lead on the local mode supply terminal on the customer interface box logic unit.	Less than 10 ohms resistance? YES Repair : Replace the remote panel control panel. Refer to Procedure 015-025 (/qs3/pubsys2/xml/en/procedures/115/115-015-025.html).	Repair complete.
	Less than 10 ohms resistance? NO Repair : Replace the faulty wire. Refer to Procedure 015-023 (/qs3/pubsys2/xml/en/procedures/115/115-015-023.html).	Repair complete.