

Engine Room Panel Local/Remote Switch Does Not Switch to Remote

Symptoms

- Engine will **not** crank when the start button is pushed at the remote panel.
- Engine will **only** crank when the start button is pushed at the engine room panel.

How To Use This Tree

This symptom tree can be used to troubleshoot engine start symptoms. Start by performing Step 1 troubleshooting. Step 2 will ask a series of questions and will provide a list of troubleshooting steps to perform, depending on the symptom.

Shoptalk

- To initiate engine crank from the engine room panel the following panel parameters **must** be met:
- The engine room panel power switch on the lamp illuminated.
 - The engine **must** be stopped.
- To initiate engine crank from the remote panel the following panel parameters **must** be met:
- The remote panel power lamp illuminated.
 - The local start **only** lamp is **not** illuminated.
 - The engine **must** be stopped.

Troubleshooting Summary

STEPS		SPECIFICATIONS
STEP 1.	Check Customer Interface Box Logic Unit	
	STEP 1A. Check Local Mode Lamp	Is the local mode lamp illuminated?
	STEP 1B. Shut Off Local Mode Lamp	Is the local mode lamp illuminated?
STEP 2.	Check Remote Panel	
	STEP 2A. Check Remote Panel Local Start Only Lamp	Is the local start only lamp illuminated?

STEPS		SPECIFICATIONS
STEP 3.	Check Customer Interface Box Wiring	
	STEP 3A. Check the Remote Panel Local Mode Supply Wire	24 VDC?
STEP 4.	Check Panel System Cable	
	STEP 4A. Check the Remote Panel Cable	Greater than 100k ohms resistance?

STEP 1. Check Customer Interface Box Logic Unit

STEP 1A. Check Local Mode Lamp

Conditions :

- Locate engine room panel
- Power switch on and lamp illuminated
- Open customer interface box.

Action	Specification/Repair	Next Step
Check local mode lamp. • Push the local start only button. • Verify local mode lamp illuminated on the customer interface box logic unit.	Is the local mode lamp illuminated? YES	1B
	Is the local mode lamp illuminated? NO Repair : Refer to Engine Room Panel Local/Remote Switch Fails to Switch to Local symptom tree.	Repair complete.

STEP 1B. Shut Off Local Mode Lamp

Conditions :

- Locate engine room panel
- Power switch on and lamp illuminated
- Open customer interface box.

Action	Specification/Repair	Next Step
Check local mode lamp. • Push the local start only button. • Verify local mode lamp is not illuminated on the customer interface box logic unit.	Is the local mode lamp illuminated? YES Repair : Refer to Engine Room Panel Local/Remote Switch Fails to Switch to Remote symptom tree.	Repair complete.
	Is the local mode lamp illuminated? NO	2A

STEP 2. Check Remote Panel

STEP 2A. Check Remote Panel Local Start Only Lamp

Conditions :

- Locate remote panel
- Power lamp illuminated.

Action	Specification/Repair	Next Step
Is the local start lamp illuminated?	Is the local start only lamp illuminated? YES	3A
	Is local start only lamp illuminated? NO	Repair complete.

STEP 3. Check Customer Interface Box Wiring

STEP 3A. Check the Remote Panel Local Mode Supply Wire

Conditions :

- Open the customer interface box
- Disconnect engine room cable at connector C7 from the customer interface box
- Disconnect remote panel cable at customer interface box X4 connector.

Action	Specification/Repair	Next Step
Check the remote panel local mode supply wire. • Place the positive test lead on the remote panel local mode supply pin on the customer interface box logic unit. • Place the negative test lead on the remote panel return terminal on the customer interface box logic unit.	24 VDC? YES Repair : Replace the customer interface box logic unit. Refer to Procedure 015-023 (/qs3/pubsys2/xml/en/procedures/115/115-015-023.html).	Repair complete.
	24 VDC? NO	4A

STEP 4. Check Panel System Cable

STEP 4A. Check the Remote Panel Cable

Conditions :

- Disconnect remote panel cable at customer interface box X4 connector and remote panel connector.

Action	Specification/Repair	Next Step

Check the remote panel local mode supply wire. • Place one test lead on the remote panel local mode supply terminal on the cable. • Place the other test lead on another wire terminal on the cable. • Repeat for all other wire terminals on the cable.	Greater than 100k ohms resistance? YES Repair : Replace the control panel. Refer to Procedure 015-025 (/qs3/pubsys2/xml/en/procedures/115/115-015-025.html).	Repair complete.
	Greater than 100k ohms resistance? NO Repair : Replace the cable.	Repair complete.