

Remote Panel Indicates Incorrect Assignment

Symptoms

- The remote panel indicates the engine room panel is **not** in the local start **only** mode.
- The engine room panel indicates that local start **only** mode is active.

How To Use This Tree

This symptom tree can be used to troubleshoot panel symptoms. Start by performing Step 1 troubleshooting. Step 2 will ask a series of questions and will provide a list of troubleshooting steps to perform, depending on the symptom.

Shoptalk

Troubleshooting Summary

STEPS		SPECIFICATIONS
STEP 1.	Check Local Start Only Lamp Operation	
	STEP 1A. Check Engine Room Panel Local Start Only Button and Lamp	Lamp illuminated?
STEP 2.	Check Remote Panel Control Panel	
	STEP 2A. Check for Voltage to Control Panel	24 VDC?
STEP 3.	Check Panel System Cable	
	STEP 3A. Check Remote Panel Cable	Less than 10 ohms resistance?
STEP 4.	Check Customer Interface Box Wiring	
	STEP 4A. Check Remote Local Mode Supply Wire	Less than 10 ohms resistance?
	STEP 4B. Check Remote Panel Return Wire	Less than 10 ohms resistance?

STEP 1. Check Local Start Only Lamp Operation

STEP 1A. Check Engine Room Panel Local Start Only Button and Lamp

Conditions :

- Verify that engine room panel power switch is on and lamp illuminated.

Action	Specification/Repair	Next Step
Verify that remote panel power lamp is illuminated. • Press the local start only on button on the engine room panel. • Verify that the local start only lamp is illuminated on the engine room panel.	Lamp illuminated? YES	2A
	Lamp illuminated? NO	Repair complete.
	Repair : Refer to Engine Room Panel Indicates Incorrect Assignment symptom tree.	

STEP 2. Check Remote Panel Control Panel

STEP 2A. Check for Voltage to Control Panel

Conditions :

- Verify engine room panel local start **only** lamp is illuminated
- Open the remote panel.

Action	Specification/Repair	Next Step
--------	----------------------	-----------

Check voltage to control panel. • Disconnect remote panel local mode supply wire from control panel X4 connector. • Disconnect remote panel return wire from control panel X4 connector. • Place the positive test lead on the remote panel local mode supply wire. • Place the negative test lead on the remote panel return wire.	24 VDC? YES Repair : Replace the remote panel control panel. Refer to Procedure 015-025 (/qs3/pubsys2/xml/en/procedures/115/115-015-025.html).	Repair complete.
	24 VDC? NO	3A

STEP 3. Check Panel System Cable

STEP 3A. Check Remote Panel Cable

Conditions :

- Locate and open customer interface box
- Locate and open remote panel
- Disconnect remote panel cable from the X4 connector in the customer interface box.

Action	Specification/Repair	Next Step

Check the remote panel cable. • Install a jumper between remote panel local mode supply terminal and the remote panel return terminal on remote control panel X4 in the remote control panel. • Place one test lead on the remote panel local mode supply wire. • Place the other test lead on the remote panel return wire.	Less than 10 ohms resistance? YES	4A
	Less than 10 ohms resistance? NO Repair : Replace the cable.	Repair complete.

STEP 4. Check Customer Interface Box Wiring

STEP 4A. Check Remote Panel Local Mode Supply Wire

Conditions :

- Open the customer interface box
- Disconnect connector C7 from customer interface box.

Action	Specification/Repair	Next Step

Check the remote panel local mode supply wire. - Place one test lead on the remote panel local mode supply terminal in customer interface box X4 connector. - Place the other test lead on the local mode supply pin in connector C7.	Less than 10 ohms resistance? YES	4B
	Less than 10 ohms resistance? NO Repair : Replace the faulty wire. Refer to Procedure 015-023 (/qs3/pubsys2/xml/en/procedures/115/115-015-023.html).	Repair complete.

STEP 4B. Check Remote Panel Return Wire		
Conditions : - Open the customer interface box - Disconnect connector C7 from customer interface box.		
Action	Specification/Repair	Next Step

Check the remote panel return wire. - Place one test lead on the remote panel return terminal on the customer interface box X4 connector. - Place the other test lead on the engine room panel return pin in connector C7.	Less than 10 ohms resistance? YES Repair : Replace the remote panel control panel. Refer to Procedure 015-025 (/qs3/pubsys2/xml/en/procedures/115/115-015-025.html).	Repair complete.
	Less than 10 ohms resistance? NO Repair : Replace the wire. Refer to Procedure 015-025 (/qs3/pubsys2/xml/en/procedures/115/115-015-025.html).	Repair complete.