

Engine Room Panel Indicates Incorrect Assignment

Symptoms

- The remote panel indicates the engine room panel is in the local mode.
- The local mode lamp is **not** illuminated on the engine room control panel.

How To Use This Tree

This symptom tree can be used to troubleshoot panel symptoms. Start by performing Step 1 troubleshooting. Step 2 will ask a series of questions and will provide a list of troubleshooting steps to perform, depending on the symptom.

Shoptalk

Troubleshooting Summary

STEPS		SPECIFICATIONS
STEP 1.	Check Engine Room Panel Local Start Only Button Operation	
	STEP 1A. Check Remote Panel Local Start Only Lamp	Lamp illuminated?
STEP 2.	Check Engine Room Panel Control Panel	
	STEP 2A. Check for Voltage to Control Panel	Lamp illuminated?

STEP 1. Check Engine Room Panel Local Start Only Button Operation

STEP 1A. Check Remote Panel Local Start Only Lamp

Conditions :

- Verify that engine room panel power switch is on and lamp illuminated.

Action	Specification/Repair	Next Step
--------	----------------------	-----------

Verify that remote panel power lamp is illuminated. - Press the local start only on button on the engine room panel. - Verify that the local start only lamp is illuminated on the remote panel.	Lamp illuminated? YES	2A
	Lamp illuminated? NO Repair : Refer to Remote Panel Indicates Incorrect Assignment symptom tree.	Repair complete.

STEP 2. Check Engine Room Panel Control Panel

STEP 2A. Check for Voltage to Control Panel

Conditions :

- Press local start **only** on button on the engine room panel.

Action	Specification/Repair	Next Step
Check the engine room panel local start only lamp.	Lamp illuminated? YES	Repair complete.
	Lamp illuminated? NO Repair : Replace the engine room panel control panel. Refer to Procedure 015-024 (/qs3/pubsys2/xml/en/procedures/115/115-015-024.html).	Repair complete.

