

Engine Room Silence Function Not Working

Symptoms

- Buzzer will **not** silence when silence button pushed at engine room panel.
- Buzzer will silence when silence button pushed at remote panel.

How To Use This Tree

This symptom tree can be used to troubleshoot alarm silence symptoms. Start by performing Step 1 troubleshooting. Step 2 will ask a series of questions and will provide a list of troubleshooting steps to perform, depending on the symptom.

Shoptalk

The engine room panel and remote panel each have a silence button. The ECM delivers alarm information to the customer interface box logic unit. The customer interface box logic unit delivers alarm information to the engine room panel and remote panel. The engine room panel and remote panel deliver alarm information to the operator in visual and audible format. A silence button allows the audible alarm to be silenced.

When an alarm condition occurs the audible alarm can be shut off at all panels by pressing the silence button at any panel.

Troubleshooting Summary

STEPS		SPECIFICATIONS
STEP 1.	Check Engine Room Panel	
	STEP 1A. Check Silence Button	Less than 10 ohms resistance?
STEP 2.	Check Panel Wiring	
	STEP 2A. Check Engine Room Panel Wiring	Less than 10 ohms resistance?
	STEP 2A-1. Check Engine Room Power Switch Supply Wire	Less than 10 ohms resistance?
	STEP 2A-2. Check the Engine Room Panel Alarm Silence Supply Wire	Less than 10 ohms resistance?

STEPS		SPECIFICATIONS
STEP 3.	Check Panel System Cable	
	STEP 3A. Check Engine Room Panel Cable	Less than 10 ohms resistance?
STEP 4.	Check Customer Interface Box Wiring	
	STEP 4A. Check the Engine Room Alarm Silence Supply Wire	Less than 10 ohms resistance?

STEP 1. Check Engine Room Panel

STEP 1A. Check Silence Button

Conditions :

- Locate engine room panel
- Turn engine room panel power switch off
- Disconnect control panel connector.

Action	Specification/Repair	Next Step
Verify silence button function: • Place one test lead on the engine room power switch supply terminal of the control panel connector. • Place the other test lead on the engine room panel alarm silence supply terminal of the control panel connector. • Press the silence button.	Less than 10 ohms resistance? YES	2A
	Less than 10 ohms resistance? NO Repair : Replace the engine room panel control panel. Refer to Procedure 015-024 (/qs3/pubsys2/xml/en/procedures/115/115-015-024.html).	Repair complete.

STEP 2. Check Panel Wiring

STEP 2A. Check Engine Room Panel Wiring

Conditions :

- Locate engine room panel
- Open engine room panel door.

Action	Specification/Repair	Next Step
Check engine room panel wiring. • Disconnect cable C14 from the engine room panel. • Connect one test lead to the engine room power switch supply pin at the C14 connector. • Connect the other test lead to the engine room panel alarm silence supply pin at the C14 connector. • Press the silence button.	Less than 10 ohms resistance? YES	3A
	Less than 10 ohms resistance? NO	2A1

STEP 2A-1. Check Engine Room Power Switch Supply Wire

Conditions :

- Locate engine room panel
- Open engine room panel door.

Action	Specification/Repair	Next Step
--------	----------------------	-----------

Check wires between harness connector and control panel connector. • Disconnect cable C14 from the engine room panel. • Place one test lead on the engine room power switch supply pin on connector C14. • Place the other test lead on the engine room power switch supply pin on the control panel connector.	Less than 10 ohms resistance? YES	2A2
	Less than 10 ohms resistance? NO Repair : Replace the faulty wire. Refer to Procedure 015-024 (/qs3/pubsys2/xml/en/procedures/115/115-015-024.html).	Repair complete.

STEP 2A-2. Check the Engine Room Panel Alarm Silence Supply Wire

Conditions : • Locate engine room panel • Open engine room panel door.		
Action	Specification/Repair	Next Step
Check wires between harness connector and control panel connector. • Disconnect cable C14 from the engine room panel. • Place one test lead on the engine room panel alarm silence supply pin on connector C14. • Place the other test lead on the engine room panel alarm silence supply pin on the control panel connector.	Less than 10 ohms resistance? YES	3A
	Less than 10 ohms resistance? NO Repair : Replace the fault wire. Refer to Procedure 015-024 (/qs3/pubsys2/xml/en/procedures/115/115-015-024.html).	Repair complete.

STEP 3. Check Panel System Cable

STEP 3A. Check Engine Room Panel Cable

Conditions :

- Disconnect cable connector C14 from the engine room panel
- Disconnect cable connector C7 from the customer interface box.

Action	Specification/Repair	Next Step
Check the engine room panel cable. • Install a jumper between engine room power switch supply pin and the engine room panel alarm silence supply pin in connector C14. • Place one test lead in the engine room power switch power switch supply pin in connector C7. • Place the other test lead in the engine room power switch alarm silence supply pin in connector C7.	Less than 10 ohms resistance? YES	4A
	Less than 10 ohms resistance? NO Repair : Replace the cable.	Repair complete.

STEP 4. Check Customer Interface Box Wiring

STEP 4A. Check the Engine Room Panel Alarm Silence Supply Wire

Conditions :

- Open the customer interface box
- Disconnect engine room cable at connector C7 from the customer interface box.

Action	Specification/Repair	Next Step
Check the engine room panel alarm silence supply wire. - Place one test lead on the engine room panel alarm silence supply pin in connector C7. - Place the other test lead on the engine room panel alarm silence supply terminal on the customer interface box logic unit.	Less than 10 ohms resistance? YES Repair : Replace the customer interface box logic unit. Refer to Procedure 015-023 (/qs3/pubsys2/xml/en/procedures/115/115-015-023.html).	Repair complete.
	Less than 10 ohms resistance? NO Repair : Replace the faulty wire. Refer to Procedure 015-023 (/qs3/pubsys2/xml/en/procedures/115/115-015-023.html).	Repair complete.