

Remote Panel Silence Function Not Working

Symptoms

- Buzzer will **not** silence when silence button pushed at remote panel.
- Buzzer will silence when silence button pushed at engine room panel.

How To Use This Tree

This symptom tree can be used to troubleshoot alarm silence symptoms. Start by performing Step 1 troubleshooting. Step 2 will ask a series of questions and will provide a list of troubleshooting steps to perform, depending on the symptom.

Shoptalk

The engine room panel and remote panel each have a silence button. The ECM delivers alarm information to the customer interface box logic unit. The customer interface box logic unit delivers alarm information to the engine room panel and remote panel. The engine room panel and remote panel deliver alarm information to the operator in visual and audible format. A silence button allows the audible alarm to be silenced.

When an alarm condition occurs the audible alarm can be shut off at all panels by pressing the silence button at any panel.

Troubleshooting Summary

STEPS		SPECIFICATIONS
STEP 1.	Check Remote Panel	
	STEP 1A. Check Silence Button	Less than 10 ohms resistance?
STEP 2.	Check Panel System Cable	
	STEP 2A. Check Remote Panel Cable	Less than 10 ohms resistance?
STEP 3.	Check Customer Interface Box Wiring	
	STEP 3A. Check Remote Panel Alarm Silence Supply Wire	Less than 10 ohms resistance?

STEP 1. Check Remote Panel

STEP 1A. Check Silence Button

Conditions :

- Turn engine room panel power switch off
- Locate remote panel
- Disconnect wires from control panel X4 connector.

Action	Specification/Repair	Next Step
Verify silence button function: • Place one test lead on the remote panel power switch supply terminal of the control panel X4 connector. • Place the other test lead on the remote panel alarm silence supply terminal of the control panel X4 connector. • Press the silence button.	Less than 10 ohms resistance? YES	2B
	Less than 10 ohms resistance? NO Repair : Replace the control panel. Refer to Procedure 015-024 (/qs3/pubsys2/xml/en/procedures/115/115-015-024.html).	Repair complete.

STEP 2. Check Panel System Cable

STEP 2A. Check Remote Panel Cable

Conditions :

- Locate and open customer interface box
- Disconnect remote panel cable from customer interface box X4 connector
- Locate and open remote panel.

Action	Specification/Repair	Next Step
--------	----------------------	-----------

Check the remote panel cable. • Install a jumper between remote panel power switch supply terminal and the remote panel alarm silence supply terminal on remote control panel X4 in the remote control panel. • Place one test lead on the remote panel power switch supply terminal in the remote panel cable. • Place the other test lead on the remote panel alarm silence supply terminal in the remote panel cable.	Less than 10 ohms resistance? YES	3A
	Less than 10 ohms resistance? NO Repair : Replace the cable.	Repair complete.

STEP 3. Check Customer Interface Box Wiring		
STEP 3A. Check Remote Panel Alarm Silence Supply Wire		
Conditions : • Open the customer interface box		
Action	Specification/Repair	Next Step
Empty table body for the next steps		

Check the remote panel alarm silence supply wire. - Place one test lead on the remote panel alarm silence supply wire on the customer interface box X4 connector. - Place the other test lead on the remote panel alarm silence supply terminal on the customer interface box logic unit.	Less than 10 ohms resistance? YES Repair : Replace the customer interface box logic unit. Refer to Procedure 015-023 (/qs3/pubsys2/xml/en/procedures/115/115-015-023.html).	Repair complete.
	Less than 10 ohms resistance? NO Repair : Replace the wire. Refer to Procedure 015-023 (/qs3/pubsys2/xml/en/procedures/115/115-015-023.html).	Repair complete.