

System Will Not Start After Shutdown

Symptoms

- The SDU410 unit is preventing the engine from starting after engine shutdown.

How To Use This Tree

This symptom tree can be used to troubleshoot a malfunction. Start by performing Step 1 troubleshooting. Step 2 will ask a series of questions and will provide a list of troubleshooting steps to perform, depending on the symptom.

Shoptalk

NOTE: A jumper **must** be in place at the prelubrication sensor, if prelubrication is **not** used.

Troubleshooting Summary

STEPS		SPECIFICATIONS
STEP 1.	Check the customer interface box.	
	STEP 1A. Check the customer interface box logic unit LED illumination.	
	STEP 1B. Check the DCU410 power supply wire for voltage +24-VDC.	
	STEP 1C. Check the remote start supply wire for an open.	
	STEP 1D. Check the starter relay switch signal wire for an open.	
	STEP 1E. Check the prelubrication activation signal wire for an open.	
	STEP 1F. Check the prelubrication complete signal wire for an open.	

STEPS		SPECIFICATIONS
	STEP 1G. Check the remote start supply wire for a wire-to-wire short.	
	STEP 1H. Check the starter relay switch signal wire for a wire-to-wire short.	
	STEP 1I. Check the prelubrication activation signal wire for a wire-to-wire short.	
	STEP 1J. Check the prelubrication complete signal wire for a wire-to-wire short.	
	STEP 1K. Check the remote start supply wire for a short to ground.	
	STEP 1L. Check the prelubrication activation signal wire for a short to ground.	
	STEP 1M. Check the prelubrication complete signal wire for a short to ground.	
STEP 2.	Check the OEM wiring harness.	
	STEP 2A. Check the starter relay switch signal and return wires for an open.	
	STEP 2B. Check the starter relay switch signal and return wires for a wire-to-wire short.	
	STEP 2C. Check the starter relay switch signal wire for a short to ground.	
	STEP 2D. Check the prelubrication supply and return wires for an open.	

STEPS		SPECIFICATIONS
	STEP 2E. Check the prelubrication supply and return wires for a wire-to-wire short.	
	STEP 2F. Check the prelubrication supply wire for a short to ground.	

STEP 1. Check the customer interface box.

STEP 1A. Check the customer interface box logic unit LED illumination.

Conditions :

- Open the customer interface box.

Action	Specification/Repair	Next Step
Check the crank lamp LED on the DCU 410 unit or remote panel for illumination.	Crank lamp illuminated? YES	1B
	Crank lamp illuminated? NO	Contact a Cummins® Authorized Repair Location

STEP 1B. Check the DCU410 power supply wire for voltage +24-VDC.

Conditions :

- Open the customer interface box.

Action	Specification/Repair	Next Step
--------	----------------------	-----------

Check the voltage at the battery 1 voltage (switched power) at the DCU410 unit. - Place one test on the battery 1 voltage (switched power) supply wire at the DCU410 unit. - Place the other test lead on panel ground. Refer to the appropriate circuit diagram or wiring diagram for pin and wire identification.	Less than +24-VDC? YES Repair : Check the batteries. Refer to the OEM service manual.	Repair complete
	Less than +24-VDC? NO	1C

STEP 1C. Check the remote start supply wire for an open.

Conditions : - Open the customer interface box. - Disconnect the remote start supply wire from the DCU410 unit and X4 connection.		
Action	Specification/Repair	Next Step
Check the remote start supply wire at the DCU410 unit and X4 connection for an open. - Place one test lead on the remote start supply wire at the DCU410 unit. - Place the other test lead on the remote start supply wire at the X4 connection. Refer to the appropriate circuit diagram or wiring diagram for pin and wire identification.	Less than 10 ohms? YES	1D
	Less than 10 ohms? NO Repair : Replace the wire. Refer to Procedure 015-023 (Customer Interface Box) in Section 15. (/qs3/pubsys2/xml/en/procedures/116/116-015-023.html)	Repair complete

STEP 1D. Check the starter relay switch signal wire for an open.

Conditions :

- Open the customer interface box.
- Disconnect the starter relay switch signal wire at the DCU410 unit.
- Disconnect the C1 connector.

Action	Specification/Repair	Next Step
Check the starter relay switch signal wire at the DCU410 unit and C1 connector for an open. • Place one test lead on the starter relay switch signal wire at the DCU410 unit. • Place the other test lead on the starter relay switch signal wire at the C1 connector. Refer to the appropriate circuit diagram or wiring diagram for pin and wire identification.	Less than 10 ohms? YES	1E
	Less than 10 ohms? NO Repair : Replace the wire. Refer to Procedure 015-023 (Customer Interface Box) in Section 15. (/qs3/pubsys2/xml/en/procedures/116/116-015-023.html)	Repair complete

STEP 1E. Check the prelubrication activation signal wire for an open.**Conditions :**

- Open the customer interface box.
- Disconnect the prelubrication activation signal wire from the DCU410 unit.
- Disconnect the C1 connector.

Action	Specification/Repair	Next Step
--------	----------------------	-----------

Check the prelubrication activation signal wire at the DCU410 unit and C1 connector for an open. - Place one test lead on the prelubrication activation signal wire at the DCU410 unit. - Place the other test lead prelubrication activation signal pin at the C1 connector. Refer to the appropriate circuit diagram or wiring diagram for pin and wire identification.	Less than 10 ohms? YES	1F
	Less than 10 ohms? NO Repair : Replace the wire. Refer to Procedure 015-023 (Customer Interface Box) in Section 15. (/qs3/pubsys2/xml/en/procedures/116/116-015-023.html)	Repair complete

STEP 1F. Check the prelubrication complete signal wire for an open.

Conditions :

- Open the customer interface box.
- Disconnect the prelubrication complete signal wire at the DCU410 unit.
- Disconnect the C1 connector.

Action	Specification/Repair	Next Step
--------	----------------------	-----------

Check the prelubrication complete signal wire at the DCU410 unit and C1 connector for an open. - Place one test lead on the prelubrication complete signal wire at the DCU410 unit. - Place the other test lead on the prelubrication complete signal wire at the C1 connector. Refer to the appropriate circuit diagram or wiring diagram for pin and wire identification.	Less than 10 ohms? YES	1G
	Less than 10 ohms? NO Repair : Replace the wire. Refer to Procedure 015-023 (Customer Interface Box) in Section 15. (/qs3/pubsys2/xml/en/procedures/116/116-015-023.html)	Repair complete

STEP 1G. Check the remote start supply wire for a wire-to-wire short.

Conditions : - Open the customer interface box. - Disconnect the remote start supply wire at the DCU410 unit and the X4 connection.		
Action	Specification/Repair	Next Step

Check the remote start supply at the DCU410 unit for a wire-to-wire short. - Place one test lead on the remote start supply wire at the DCU410 unit. - Place the other test lead on all other wires at the DCU410 unit. - Place one test lead on the remote start supply wire at the X4 connector. - Place the other test lead on all other wires at the X4 connector. Refer to the appropriate circuit diagram or wiring diagram for pin and wire identification.	Less than 10 ohms? YES Repair : Replace the DCU410 unit. Contact a Cummins® Authorized Repair Location.	Repair complete
	Less than 10 ohms? NO	1H

STEP 1H. Check the starter relay switch signal wire for a wire-to-wire short.

Conditions :

- Open the customer interface box.
- Disconnect the starter relay switch signal wire at the DCU410 unit.
- Disconnect the C1 connector.

Action	Specification/Repair	Next Step
--------	----------------------	-----------

Check the starter relay switch signal wire at the DCU410 unit and C1 connector for a wire-to-wire short. • Place one test lead on the starter relay switch signal wire at the DCU410 unit. • Place the other test lead on all other wires at the DCU410 unit. • Place one test lead on the starter relay switch signal pin at the C1 connector. • Place the other test lead on all other pins at the C1 connector. Refer to the appropriate circuit diagram or wiring diagram for pin and wire identification.	Less than 10 ohms? YES Repair : Replace the DCU410 unit. Contact a Cummins® Authorized Repair Location. Replace the SDU410 unit. Contact a Cummins® Authorized Repair Location.	Repair complete
	Less than 10 ohms? NO	1I

STEP 1I. Check the prelubrication activation signal wire for a wire-to-wire short.

Conditions :

- Open the customer interface box.
- Disconnect the prelubrication activation signal wire at the DCU410 unit.
- Disconnect the C1 connector.

Action	Specification/Repair	Next Step
--------	----------------------	-----------

Check the prelubrication activation signal wire at the DCU410 unit and C1 connector for a wire-to-wire short. • Place one test lead on the prelubrication activation signal wire at the DCU410 unit. • Place the other test lead on all other wires at the DCU410 unit. • Place one test lead on the prelubrication activation signal pin at the C1 connector. • Place the other test lead on all other pins at the C1 connector. Refer to the appropriate circuit diagram or wiring diagram for pin and wire identification.	Less than 10 ohms? YES Repair : Replace the DCU410 unit. Contact a Cummins® Authorized Repair Location.	Repair complete
	Less than 10 ohms? NO	1J

STEP 1J. Check the prelubrication complete signal wire for a wire-to-wire short.

Conditions :

- Open the customer interface box.
- Disconnect the prelubrication complete signal wire at the DCU410 unit.
- Disconnect the C1 connector.

Action	Specification/Repair	Next Step

Check the prelubrication complete signal wire at the DCU410 unit and C1 connector for a wire-to-wire short. • Place one test lead on the prelubrication complete signal wire at the DCU410 unit. • Place the other test lead on all other wires at the DCU410 unit. • Place one test lead on the prelubrication complete signal pin at the C1 connector. • Place the other test lead on all other pins at the C1 connector. Refer to the appropriate circuit diagram or wiring diagram for pin and wire identification.	Less than 10 ohms? YES Repair : Replace the DCU410 unit. Contact a Cummins® Authorized Repair Location.	Repair complete
	Less than 10 ohms? NO	1K

STEP 1K. Check the remote start supply wire for a short to ground.

Conditions :

- Open the customer interface box.
- Disconnect the remote start supply wire at the DCU410 unit and X4 connection.

Action	Specification/Repair	Next Step
--------	----------------------	-----------

Check the remote start supply wire at the DCU410 unit and X4 connection for a short to ground. • Place one test lead on the remote start supply wire at the DCU410 unit. • Place the other test lead on panel ground. • Place one test lead on the remote start supply wire at the X4 connection. • Place the other test lead on panel ground. Refer to the appropriate circuit diagram or wiring diagram for pin and wire identification.	Less than 10 ohms? YES Repair : Replace the DCU410 unit. Contact a Cummins® Authorized Repair Location.	Repair complete
	Less than 10 ohms? NO	1L

STEP 1L. Check the prelubrication activation signal wire for a short to ground.

Conditions :

- Open the customer interface box.
- Disconnect the prelubrication activation and complete signal wires at the DCU410 unit.
- Disconnect the C1 connector.

Action	Specification/Repair	Next Step
--------	----------------------	-----------

Check the prelubrication activation signal wire at the DCU410 unit and C1 connector for a short to ground. - Place one test lead on the prelubrication activation signal wire at the DCU410 unit. - Place the other test lead on panel ground. - Place one test lead on the prelubrication activation signal pin at the C1 connector. - Place the other test lead on panel ground. Refer to the appropriate circuit diagram or wiring diagram for pin and wire identification.	Less than 10 ohms? YES Repair : Replace the DCU410 unit. Contact a Cummins® Authorized Repair Location. Replace the SDU410 unit. Contact a Cummins® Authorized Repair Location.	Repair complete
	Less than 10 ohms? NO	1M

STEP 1M. Check the prelubrication complete signal wire for a short to ground.

Conditions : - Open the customer interface box. - Disconnect the prelubrication complete signal wire at the DCU410 unit. - Disconnect the C1 connector.		
Action	Specification/Repair	Next Step

Check the prelubrication complete signal wire at the DCU410 unit and C1 connector for a short to ground. - Place one test lead on the prelubrication complete signal wire at the DCU410 unit. - Place the other test lead on panel ground. - Place one test lead on the prelubrication complete signal pin at the C1 connector. - Place the other test lead on panel ground. Refer to the appropriate circuit diagram or wiring diagram for pin and wire identification.	Less than 10 ohms? YES Repair : Replace the DCU410 unit. Contact a Cummins® Authorized Repair Location. Replace the SDU410 unit. Contact a Cummins® Authorized Repair Location.	Repair complete
	Less than 10 ohms? NO	2A

STEP 2. Check the OEM wiring harness.

STEP 2A. Check the starter relay switch signal and return wires for an open.

Conditions :

- Disconnect the starter relay switch signal and return wires at the starting motor ring terminals.
- Disconnect the C1 connector.

Action	Specification/Repair	Next Step

Check the starter relay switch signal and return wires at the C1 connector for an open. - Place one test lead on the starter relay switch signal pin at the C1 connector. - Place the other test lead on the starter relay switch signal wire at the starting motor ring terminal. - Place one test lead on the starter relay switch return pin at the C1 connector. - Place the other test lead on the starter relay switch return wire at the starting motor ring terminal. Refer to the appropriate circuit diagram or wiring diagram for pin and wire identification.	Less than 10 ohms? YES	2B
	Less than 10 ohms? NO Repair : Replace the wire. Refer to the OEM service manual.	Repair complete

STEP 2B. Check the starter relay switch signal and return wires for a wire-to-wire short.

Conditions : Disconnect the C1 connector.		
Action	Specification/Repair	Next Step

Check the starter relay switch signal and return wires at the C1 connector for a wire-to-wire short. • Place one test lead on the starter relay switch signal pin at the C1 connector. • Place the other test lead on all other pins at the C1 connector. • Place one test lead on the starter relay switch return pin at the C1 connector. • Place the other test lead on all other pins at the C1 connector. Refer to the appropriate circuit diagram or wiring diagram for pin and wire identification.	Less than 10 ohms? YES Repair : Replace the wire or connector. • Refer to Procedure 015-023 (Customer Interface Box) in Section 15 to replace the wire. (/qs3/pubsys2/xml/en/procedures/116/116-015-023.html) • Contact a Cummins® Authorized Repair Location to replace the connector.	Repair complete
	Less than 10 ohms? NO	2C

STEP 2C. Check the starter relay switch signal wire for a short to ground.

Conditions : • Open the customer interface box. • Disconnect the C1 connector.		
Action	Specification/Repair	Next Step

Check the starter relay switch signal wire at the C1 connector for a short to ground. - Place one test lead on the starter relay switch signal pin at the C1 connector. - Place the other test lead on engine ground. Refer to the appropriate circuit diagram or wiring diagram for pin and wire identification.	Less than 10 ohms? YES Repair : Replace the wire or connector. - Refer to Procedure 015-023 (Customer Interface Box) in Section 15 to replace the wire. (/qs3/pubsys2/xml/en/procedures/116/116-015-023.html) - Contact a Cummins® Authorized Repair Location to replace the connector.	Repair complete
	Less than 10 ohms? NO	2D

STEP 2D. Check the prelubrication supply and return wires for an open.

Conditions :

- Disconnect the C1 connector.
- Disconnect the prelubrication sensor.

Action	Specification/Repair	Next Step

Check the prelubrication supply and return wires for an open. - Place one test lead on the prelubrication supply pin at the C1 connector. - Place the other test lead on the prelubrication supply pin at the prelubrication sensor connector. - Place one test lead on the prelubrication return pin at the C1 connector. - Place the other test lead on the prelubrication return pin at the prelubrication sensor connector. Refer to the appropriate circuit diagram or wiring diagram for pin and wire identification.	Less than 10 ohms? YES	2E
	Less than 10 ohms? NO Repair : Replace the wire. Refer to the OEM service manual.	Repair complete

STEP 2E. Check the prelubrication supply and return wires for a wire-to-wire short.

Conditions :

- Disconnect the C1 connector.
- Disconnect the prelubrication sensor.

Action	Specification/Repair	Next Step
--------	----------------------	-----------

Check the prelubrication supply and return wires for a wire-to-wire short. - Place one test lead on the prelubrication supply pin at the C1 connector. - Place the other test lead on all other pins at the C1 connector. - Place one test lead on the prelubrication return pin at the C1 connector. - Place the other test lead on all other pins at the C1 connector. Refer to the appropriate circuit diagram or wiring diagram for pin and wire identification.	Less than 10 ohms? YES Repair : Replace the wire. Refer to the OEM service manual.	Repair complete
	Less than 10 ohms? NO	2F

STEP 2F. Check the prelubrication supply wire for a short to ground.

Conditions : - Disconnect the C1 connector. - Disconnect the prelubrication sensor.		
Action	Specification/Repair	Next Step

Check the prelubrication supply wire for a short to ground. - Place one test lead on the prelubrication supply pin at the C1 connector. - Place the other test lead on engine ground. Refer to the appropriate circuit diagram or wiring diagram for pin and wire identification.	Less than 10 ohms? YES Repair : Replace the wire. Refer to the OEM service manual.	Repair complete
	Less than 10 ohms? NO Repair : Replace the prelubrication sensor. Refer to the OEM service manual or contact a Cummins® Authorized Repair Location.	Repair complete