

ECM Torque Curve Select Signal Malfunction

Symptoms

- ECM torque curve select signal is **not** available.

How To Use This Tree

This symptom tree can be used to troubleshoot an ECM torque curve select signal. Start by performing Step 1 troubleshooting. Step 2 will ask a series of questions and will provide a list of troubleshooting steps to perform, depending on the symptom.

Shoptalk

Troubleshooting Summary

STEPS		SPECIFICATIONS
STEP 1.	Check Customer Interface Box Wiring	
	STEP 1A. Check Torque Curve Select Signal Wire for Open	Less than 10 ohms?
	STEP 1B. Check Torque Curve Select Signal Wire for Wire to Wire Short	Less than 10 ohms?
	STEP 1C. Check Torque Curve Select Signal Wire for Short to Ground	Less than 10 ohms?
STEP 2.	Check Engine Harness to Customer Interface Box Cable	
	STEP 2A. Check Torque Curve Select Signal Wire for Open	Less than 10 ohms?

STEP 1. Check Customer Interface Box Wiring

STEP 1A. Check Torque Curve Select Signal Wire for Open

Conditions :

- Open the customer interface box
- Disconnect customer interface box to engine harness cable connector C3 from the customer interface box.

Action	Specification/Repair	Next Step
Check the torque curve select signal wire for an open. • Place one test lead on the torque curve select signal pin in connector C3. • Place the other test lead on torque curve select signal terminal on the X4 connector.	Less than 10 ohms? YES	1B
	Less than 10 ohms? NO Repair : Replace the wire. Refer to Procedure 015-023 (/qs3/pubsys2/xml/en/procedures/116/116-015-023.html).	Repair complete

STEP 1B. Check Torque Curve Select Signal Wire for Wire to Wire Short

Conditions :

- Open the customer interface box
- Disconnect customer interface box to engine harness cable connector C3 from the customer interface box.

Action	Specification/Repair	Next Step
Check the torque curve select signal wire for wire to wire short. • Place one test lead on the torque curve select signal pin in connector C3. • Place the other test lead on each of the remaining terminals in X4 connector.	Less than 10 ohms? YES Repair : Replace the wire. Refer to Procedure 015-023 (/qs3/pubsys2/xml/en/procedures/116/116-015-023.html).	Repair complete
	Less than 10 ohms? NO	1C

STEP 1C. Check Torque Curve Select Signal Wire for Short to Ground

Conditions :

- Open the customer interface box
- Disconnect customer interface box to engine harness cable connector C3 from the customer interface box.

Action	Specification/Repair	Next Step
Check the torque curve select signal wire for short to ground. • Place one test lead on the torque curve select signal pin in connector C3. • Place the other test lead on panel ground.	Less than 10 ohms? YES Repair : Replace the wire. Refer to Procedure 015-023 (/qs3/pubsys2/xml/en/procedures/116/116-015-023.html).	Repair complete
	Less than 10 ohms? NO	2A

STEP 2. Check Engine Harness to Customer Interface Box Cable

STEP 2A. Check Torque Curve Select Signal Wire for Open

Conditions :

- Disconnect customer interface box to engine harness cable connector C3 from the customer interface box
- Disconnect customer interface box to engine harness cable connector C10 from the engine harness.

Action	Specification/Repair	Next Step
--------	----------------------	-----------

Check torque curve select signal wire. • Place a jumper between the torque curve select signal pin and the droop select pin in the C10 connector. • Place one test lead in the torque curve select signal pin of the C3 connector. • Place the other test lead in the droop select signal pin of the C3 connector.	Less than 10 ohms? YES Repair : Refer to Section TF in the Troubleshooting and Repair Manual, QSK19 CM850 Modular Common Rail System Series Engines, Bulletin 4021493 (/qs3/portal/manualviewer.html?path=/qs3/pubsys2/xml/en/outlines/4021493.html), or the Troubleshooting and Repair Manual, Electronic Control System, QSK38, QSK50, and QSK60, CM850 Modular Common Rail System Series Engines, Bulletin 4021533 (/qs3/portal/manualviewer.html?path=/qs3/pubsys2/xml/en/outlines/4021533.html), or refer to the OEM service manual.	Repair complete
	Less than 10 ohms? NO Repair : Replace the cable.	Repair complete