

Engine Shutdown Unit Does Not Indicate Sensor/Line Malfunction

Symptoms

- A yellow fault LED is illuminated on the SDU410 and that channel is **not** protecting the engine.

How To Use This Tree

This symptom tree can be used to troubleshoot a malfunction. Start by performing Step 1 troubleshooting. Step 2 will ask a series of questions and will provide a list of troubleshooting steps to perform, depending on the symptom.

Shoptalk

NOTE: Check the DCU410 troubleshooting manual before performing any of the following steps. If there is communication, then the engine shutdown was **not** caused by the SDU410. If the LED is illuminated on the SDU410 unit, then the problem is in the DCU410 or the SDU410 unit. If no LED is illuminated then the SDU410 is **not** the root of the cause.

Troubleshooting Summary

STEPS		SPECIFICATIONS
STEP 1.	Check customer interface box wiring	
	STEP 1A. Check the Modicon™ communication bus supply and return wires for an open.	Less than 10 ohms?
	STEP 1B. Check the Modicon™ communication bus supply and return wires for a wire-to-wire short.	Less than 10 ohms?
	STEP 1C. Check the Modicon™ communication bus supply wire for a short to ground.	Less than 10 ohms?

STEP 1. Check customer interface box wiring

STEP 1A. Check the Modicon™ communication bus supply and return wires for an open.

Conditions :

- Open the customer interface box.
- Disconnect the Modicon™ communication bus supply and return wire at the SDU410 and DCU410 terminal strips.

Action	Specification/Repair	Next Step
Check the signal and return wires for an open. • Place one test lead on the shutdown unit Modicon™ communication bus supply wire at the SDU410 unit. • Place the other test lead on the shutdown unit Modicon™ communication bus supply wire at the DCU410 unit. • Place one test lead on the shutdown unit Modicon™ communication bus return wire at the SDU410 unit. • Place the other test lead on the shutdown unit Modicon™ communication bus return wire at the DCU410 unit. Refer to the appropriate circuit diagram or wiring diagram for pin and wire identification.	Less than 10 ohms? YES	1B
	Less than 10 ohms? NO Repair : Replace the wire. Refer to Procedure 015-023 (Customer Interface Box) in Section 15. (/qs3/pubsys2/xml/en/procedures/116/116-015-023.html)	Repair complete

STEP 1B. Check the Modicon™ communication bus supply and return wires for a wire-to-wire short.

Conditions : • Open the customer interface box. • Disconnect the Modicon™ communication bus supply and return wires at the SDU410 and DCU410 terminal strips.		
Action	Specification/Repair	Next Step

Check the supply and return wires for a wire-to-wire short.

- Place one test lead on the shutdown unit Modicon™ communication bus supply wire at the SDU410 unit.
- Place the other test lead on each of the other wires at the SDU410 unit.
- Place one test lead on the shutdown unit Modicon™ communication bus supply wire at the DCU410 unit.
- Place the other test lead on each of the other wires at the DCU410 unit.
- Place one test lead on the shutdown unit Modicon™ communication bus return wire at the SDU410 unit.
- Place the other test lead on each of the other wires at the SDU410 unit.
- Place one test lead on the shutdown unit Modicon™ communication bus return wire at the DCU410 unit.
- Place the other test lead on each of the other wires at the DCU410 unit.

Less than 10 ohms?

YES

Repair :

Replace the wire. Refer to Procedure 015-023 (Customer Interface Box) in Section 15.
(/qs3/pubsys2/xml/en/procedures/116/116-015-023.html)

Repair complete

Refer to the appropriate circuit diagram or wiring diagram for pin and wire identification.	Less than 10 ohms? NO	1C
---	---------------------------------	-----------

STEP 1C. Check the Modicon™ communication bus supply wire for a short to ground.

Conditions :

- Open the customer interface box.
- Disconnect the Modicon™ communication bus supply wire at the SDU410 and DCU410 units.

Action	Specification/Repair	Next Step
Check the supply wire for short to ground. • Place one test lead on the shutdown unit Modicon™ communication bus supply wire at the SDU410 unit. • Place the other test lead on panel ground. • Place one test lead on the shutdown unit Modicon™ communication bus supply wire at the DCU410 unit. • Place the other test lead on panel ground. Refer to the appropriate circuit diagram or wiring diagram for pin and wire identification.	Less than 10 ohms? YES Repair : Replace the wire. Refer to Procedure 015-023 (Customer Interface Box) in Section 15. (/qs3/pubsys2/xml/en/procedures/116/116-015-023.html)	Repair complete
	Less than 10 ohms? NO	Contact a Cummins® Authorized Repair Location

